



MARINE ENGINE

6LPA-STP2 6LPA-STZP2

(en) English

California Proposition 65 Warning

Diesel engine exhaust and some of its constituents are known to the state of California to cause cancer, birth defects, and other reproductive harm.

California Proposition 65 Warning

Battery posts, terminals, and related accessories contain lead and lead compounds, chemicals known to the state of California to cause cancer and reproductive harm.

Wash hands after handling.

Disclaimers:

All information, illustrations and specifications in this manual are based on the latest information available at the time of publishing. The illustrations used in this manual are intended as representative reference views only. Moreover, because of our continuous product improvement policy, we may modify information, illustrations and/or specifications to explain and/or exemplify a product, service or maintenance improvement. We reserve the right to make any change at any time without notice. Yanmar and **YANMAR** are registered trademarks of YANMAR CO., LTD. in Japan, the United States and/or other countries.

All Rights Reserved:

No part of this publication may be reproduced or used in any form by any means - graphic, electronic, or mechanical, including photocopying, recording, taping, or information storage and retrieval systems - without the written permission of YANMAR CO., LTD.

Please review and comply with the applicable laws and regulations of the international export control regimes at the territory or country where the product and manual are intended to be imported and used.


OPERATION MANUAL	MODEL	6LPA-STP2, 6LPA-STZP2
OPERATION MANUAL	CODE	0A6LP-EN0014

TABLE OF CONTENTS

Pag	је
Introduction1	
Record of Ownership 2	
Safety 3	
Safety Precautions	 - -
Location of Safety Decals 8	
Product Overview9)
Yanmar 6LPA Series Features and Applications 9 New Engine Break-In10)
Component Identification	
Non-Service Side 12	<u>-</u>
Nameplates13	}
Function of Major Components14	ļ
Control Equipment	5
Before You Operate)
Introduction	

TABLE OF CONTENTS

Diesel Fuel	26
Diesel Fuel Specifications	
Handling of Diesel Fuel	20 28
Fuel Tank (Option)	
Fuel System	
Filling the Fuel Tank	
Bleeding the Fuel System	
Engine Oil	
Engine Oil Specifications	
Engine Oil Viscosity	
Checking the Engine Oil	
Adding Engine Oil	32
Marine Drive Oil	33
Mercruiser® Bravo Stern Drive Oil	
Specifications	
Checking and Adding Marine Drive Oil	33
Checking and Adding Power Steering Oil	00
(6LPA-STZP2 Models)	
Engine Coolant	
Engine Coolant Specifications	
Coolant (Closed Cooling System) Checking and Adding Coolant	
· ·	
Cranking the Engine	
Engine Operation	
Introduction	39
Safety Precautions	39
Starting the Engine	40
If the Engine Fails to Start	
Starting at Low Temperatures	
After the Engine has Started	
Remote Control Handle Operation	
Acceleration and Deceleration	
Shifting the Engine	
Cautions During Operation	46
Shutting Down the Engine	
Normal Shutdown	47
Checking the Engine after Operation	48
Periodic Maintenance	49
Introduction	49
Cofety Dracoutions	



Precautions	50
The Importance of Periodic Maintenance	
Performing Periodic Maintenance	
	50
, , ,	50
• • • • • • • • • • • • • • • • • • •	50
	50
Ask Your Authorized Yanmar Marine Dealer or	
	50
3 3	51
Periodic Maintenance Schedule	52
	54
- ···· , · · · · · · · · · · · · · · · · · · ·	54
After Initial 50 Hours of Operation	
Every 50 Hours of Operation	
Every 125 Hours of Operation	
After Initial 250 Hours of Operation	
· · · · · · · · · · · · · · · · · · ·	61
Every 500 Hours of Operation	
Every 1000 Hours of Operation Every 1250 Hours of Operation	
Troubleshooting	
Safety Precautions	
Troubleshooting after Starting	70
Troubleshooting Information	71
Troubleshooting Chart	72
Long-Term Storage	75
Prepare Engine for Long-Term Storage	75
Drain Seawater Cooling System	76
Returning the Engine to Service	77
Specifications	79
Principal Engine Specifications	79
	80
System Diagrams	81
Piping Diagrams	81
Wiring Diagrams	

This Page Intentionally Left Blank

INTRODUCTION

Welcome to the world of Yanmar Marine! Yanmar Marine offers engines, drive systems and accessories for all types of boats, from runabouts to sailboats, and from cruisers to mega yachts. In marine leisure boating, the worldwide reputation of Yanmar Marine is second to none. We design our engines to respect nature. This means quieter engines, with minimal vibrations, cleaner than ever. All of our engines meet applicable regulations, including emissions, at the time of manufacture.

To help you enjoy your Yanmar 6LPA series engine for many years to come, please follow these recommendations:

- Read and understand this Operation Manual before you operate the machine to ensure that you follow safe operating practices and maintenance procedures.
- Keep this *Operation Manual* in a convenient place for easy access.
- If this Operation Manual is lost or damaged, order a new one from your authorized Yanmar Marine dealer or distributor.


- Make sure this manual is transferred to subsequent owners. This manual should be considered a permanent part of the engine and remain with it.
- Constant efforts are made to improve the quality and performance of Yanmar products, so some details included in this Operation Manual may differ slightly from your engine. If you have any questions about these differences. please contact your authorized Yanmar Marine dealer or distributor.
- The specifications and components (instrument panel, fuel tank, etc.) described in this manual may differ from ones installed on your vessel. Please refer to the manual provided by the manufacturer of these components.
- Refer to the Yanmar Limited Warranty Handbook for a complete warranty description.

INTRODUCTION

RECORD OF OWNERSHIP

Take a few moments to record the information you need when you consult Yanmar for service, parts or documentation.

Engine Model:	 	
Engine Serial No.:	 	
Date Purchased:		
Dealer:	<u> </u>	
Dealer Phone:		



SAFETY

Yanmar considers safety of great importance and recommends that anyone that comes into close contact with its products, such as those who install, operate, maintain or service Yanmar products, exercise care, common sense and comply with the safety information in this manual and on the machine's safety decals. Keep the labels from becoming dirty or torn and replace them if they are lost or damaged. Also, if you need to replace a part that has a label attached to it, make sure you order the new part and label at the same time.



This safety alert symbol appears with most safety statements. It means attention, become alert, your safety is involved! Please read and abide by the message that follows the safety alert symbol.

🛕 DANGER

Indicates a hazardous situation which. if not avoided, will result in death or serious injury.

▲ WARNING

Indicates a hazardous situation which. if not avoided, could result in death or serious injury.

A CAUTION

Indicates a hazardous situation which. if not avoided, could result in minor or moderate injury.

NOTICE

Indicates a situation which can cause damage to the machine, personal property and/or the environment, or cause the equipment to operate improperly.

SAFETY PRECAUTIONS

General Information

There is no substitute for common sense and careful practices. Improper practices or carelessness can cause burns, cuts, mutilation, asphyxiation, other bodily injury or death. This information contains general safety precautions and guidelines that must be followed to reduce risk to personal safety. Special safety precautions are listed in specific procedures. Read and understand all of the safety precautions before operation or performing repairs or maintenance.

Before You Operate

A DANGER

The safety messages that follow have DANGER level hazards.

Never permit anyone to install or operate the engine without proper training.

•Read and understand this Operation Manual before you operate or service the engine to ensure that you follow safe operating practices and maintenance procedures.

- Safety signs and labels are additional reminders for safe operating and maintenance techniques.
- Consult authorized Yanmar Marine dealer or distributor for additional training.

During Operation and Maintenance

A WARNING

The safety messages that follow have WARNING level hazards.

Explosion Hazard



While the engine is running or the battery is charging, hydrogen gas is being produced and can be easily ignited. Keep the area around the battery

well-ventilated and keep sparks, open flames and any other form of ignition out of the area.

Fire and Explosion Hazard

Diesel fuel is flammable and explosive under certain conditions.

Never use a shop rag to catch the fuel.

Wipe up all spills immediately.

Never refuel with the engine running.

Fire Hazard



Undersized wiring systems can cause an electrical fire. Never use improper capacity of fuses.

Store any containers containing fuel or other flammable products in a well-ventilated area, away from any combustibles or source of ignition.

Store any equipment in a designated area away from moving parts.

Never use the engine compartment for storage.

▲ WARNING

Sever Hazard



Rotating parts can cause severe injury or death. Never wear jewelry, unbuttoned cuffs, ties or loose-fitting clothing and

always tie long hair back when working near moving/rotating parts such as the flywheel or PTO shaft. Keep hands, feet and tools away from all moving parts.

Alcohol and Drug Hazard



Never operate the engine while under the influence of alcohol or drugs, or when feeling ill.

Exposure Hazard



Always wear personal protective equipment including appropriate clothing, gloves, work

shoes, and eye and hearing protection as required by the task at hand.

Sudden Movement Hazard

Never operate the engine while wearing a headset to listen to music or radio because it will be difficult to hear the warning signals.

Burn Hazard



Some of the engine surfaces become very hot during operation and shortly after shutdown. Keep hands and other body

parts away from hot engine surfaces.

Exhaust Hazard



Never block windows, vents or other means of ventilation if the engine is operating in an enclosed

area. All internal combustion engines create carbon monoxide gas during operation and special precautions are required to avoid carbon monoxide poisoning.

A CAUTION

The safety messages that follow have CAUTION level hazards.

Poor Lighting Hazard

Ensure that the work area is adequately illuminated. Always install wire cages on portable safety lamps.

Tool Hazard

Always use tools appropriate for the task at hand and use the correct size tool for loosening or tightening machine parts.

Flying Object Hazard

Always wear eye protection when servicing the engine or when using compressed air or high-pressure water. Dust, flying debris, compressed air, pressurized water or steam may injure your eyes.

Coolant Hazard



Wear eye protection and rubber gloves when you handle engine coolant. If

contact with the eyes or skin should occur, flush eyes and wash immediately with clean water.

NOTICE

The safety messages that follow have NOTICE level hazards.

It is important to perform daily checks as listed in the *Operation Manual*. Periodic maintenance prevents unexpected downtime, reduces the number of accidents due to poor engine performance and helps extend the life of the engine.

Consult authorized Yanmar Marine dealer or distributor if you need to operate the engine at high altitudes. At high altitudes the engine will lose power, run rough and produce exhaust gases that exceed the design specifications.



Always be environmentally responsible.

Follow the guidelines of the EPA or other governmental

agencies for the proper disposal of hazardous materials such as engine oil, diesel fuel and engine coolant. Consult the local authorities or reclamation facility.

Never dispose of hazardous materials by dumping them into a sewer, on the ground, or into ground water or waterways.

If a Yanmar Marine Engine is installed at an angle that exceeds the specifications stated in the Yanmar Marine *Installation Manuals*, engine oil may enter the combustion chamber causing excessive engine speed, white exhaust smoke and serious engine damage. This applies to engines that run continuously or those that run for short periods of time.



NOTICE

If you have an installation with two or three engines and only one engine is operating, the water pickup (thru-hull) of the non-running engine(s) should be closed. This will prevent water from being forced past the seawater pump and eventually finding its way into the engine. The result of water entering the engine could cause seizure or other serious problems.

If you have an installation with two or three engines, and only one engine is operating, please note that if the propeller shaft thru-hull (stuffing box) is lubricated by engine water pressure and the engines are interconnected, care must be taken that water from the running engine does not enter the exhaust of the non-running engine(s). This water could cause seizure of the non-running engine(s). Consult authorized Yanmar Marine dealer or distributor for a complete explanation of this condition.

If you have an installation with two or three engines, and only one engine is operating, it is important to limit the amount of throttle applied to the running engine. If you observe black smoke or movement of the throttle does not increase engine speed. you are overloading the engine that is running. Immediately throttle back to approximately 2/3 throttle or to a setting where the engine performs normally. Failure to do so may cause the running engine to overheat or cause excess carbon buildup which may shorten the engine's life.

Never turn off the battery switch (if equipped) or short the battery cables during operation. Damage to the electrical system will result.

LOCATION OF SAFETY DECALS

Figure 1 show the location of safety decals on Yanmar 6LPA series marine engines.

■ 6LPA engines




Figure 1

No.	Part No.
1	120324-07240
2	128296-07260
3	119773-07280
4	128296-07300
5	128296-07360

Note: Figure 1 shows an overhead view of the 6LPA engine.

PRODUCT OVERVIEW

YANMAR 6LPA SERIES **FEATURES AND APPLICATIONS**

The 6LPA series are four-stroke direct injection diesel engines equipped with liquid coolant sys tems.

The 6LPA-STP2 engines are equipped with a marine gear (ZF63A1, KMH50A or KMH50V).

The 6LPA-STZP2 engines are equipped with a stern drive (ZT370 or Mercruiser Bravo).

This engine is designed for recreational craft use.

It is recommended that new vessels be propped so the engines can operate at 50 to 100 min⁻¹ above the fuel stop power engine speed to allow for some added weight and hull resistance.

Failure to do so can lead to reduced vessel performance, lead to increased smoke levels and cause permanent damage to your engine.

The engine must be installed correctly with coolant lines, exhaust gas lines and electrical wiring. Any auxiliary equipment attached to the engine should be easy to use and accessible for service. To handle the drive equipment, propulsion systems (including the propeller) and other inboard equipment, always observe the instructions and cautions given in the operation manuals supplied by the shipyard and equipment manufacturers.

The 6LPA series engines are designed to be operated at maximum throttle*1 for less than 5 % of total engine time (30 minutes out of every 10 hours) and cruising speed*2.

The laws of some countries may require hull and engine inspections, depending on the use, size and cruising area of the boat. The installation, fitting and surveying of this engine all require specialized knowledge and engineering skills. See Yanmars local subsidiary in your region or your authorized Yanmar Marine dealer or distributor.

^{*1} maximum throttle: fuel stop power engine speed

^{*2} cruising speed: fuel stop power engine speed -200 min⁻¹ or less

PRODUCT OVERVIEW

New Engine Break-In

As with all reciprocating engines, the way your engine is operated during its first 50 hours of operation plays a very significant role in determining how long it will last and how well the engine will perform over its lifetime.

A new Yanmar diesel engine must be operated at suitable speeds and power settings during the break-in period to make the sliding parts, such as piston rings, break-in properly and to stabilize engine combustion.

During the break-in period, the engine coolant temperature gauge should be monitored; temperature should be between 71 and 87 °C (160 and 190 °F).

During the first 10 hours of operation, the engine should be run at maximum engine speed minus 400 to 500 min⁻¹ (approximately 60 to 70 % of load) most of the time. This will ensure the sliding parts break in properly. During this period, avoid operating at maximum engine speed and load to avoid damaging or scoring sliding parts.

NOTICE

Do not operate at WOT (Wide Open Throttle) for more than a minute at a time during the first 10 hours of operation.

Do not operate the engine at low idle or at low speed and light load for more than 30 minutes at a time. Since unburned fuel and engine oil will adhere to the piston rings when operating at low speeds for long periods, this will interfere with proper movement of the rings and the engine oil consumption may increase. Low idle speed does not allow break-in of sliding parts.

If operating engine at low speed and light load, you must race the engine to clean the carbon from the cylinders and fuel injection valve.

Perform this procedure in open waters:

- With the clutch in NEUTRAL, accelerate from the low-speed position to the high-speed position briefly.
- · Repeat this process five times.

Once past the initial 10 hours until 50 hours, the engine should be used over its full operating range, with special emphasis on running at relatively high power settings. This is not the time for an extended cruise at idle or low speed. The boat should be run at maximum speed minus 400 min-1 most of the time (approximately 70 % load), with a 10 minute run at maximum minus 200 min-1 (approximately 80 % load) every 30 minutes and a 4 to 5 minute period of operation at WOT (Wide Open Throttle) once each 30 minutes. During this period, be sure not to operate your engine at low speed and light load for more than 30 minutes. If operating engine at low speed and light load by necessity, just after the low idle operation, be sure to race the engine.


To complete engine break-in, perform After Initial 50 Hours of Operation maintenance procedures. See After Initial 50 Hours of Operation on page 56.



COMPONENT IDENTIFICATION

Service Side (Left Side as Viewed from Propeller)

Note: 6LPA-STZP2 with stern drive shown. Components marked with an * are for 6LPA-STZP2 only.




- 1 Fuel cooler
- 2 Fuel filter
- 3 Power steering oil cooler*
- 4 Engine oil filter
- 5 Intercooler
- 6 Mixing elbow

- 7 Engine oil cooler
- 8 Starter
- 9 Engine oil cooler
- 10 Fuel injection pump
- 11 Seawater pump
- 12 Stern drive

Figure 1

Non-Service Side



- 1 Turbocharger
- 2 Engine nameplate (on rocker arm cover)
- 3 Fresh water (coolant) tank
- 4 Power steering oil tank*
- 5 Fresh water filler cap

- 6 Engine oil filler cap 7 Power steering oil pump*

- 8 Alternator 9 Engine oil dipstick 10 Fresh water cooler
- 11 V-belt

Figure 2

NAMEPLATES

The nameplate of Yanmar 6LPA series engines is shown in Figure 3. The nameplate is located on the engine rocker arm cover. Check the engine's model, output, rpm and serial number on the nameplate. Replace if damaged or lost.





Figure 3

FUNCTION OF MAJOR COMPONENTS

Name of component	Function
Fuel filter	Removes dirt and water from the fuel. The filter is a cartridge type, and the inner element should be replaced before clogging occurs. A water separator is on the bottom of the filter and should be drained periodically.
Fuel feed pump	A mechanical pump that pumps fuel from the tank to the fuel injection pump. It is built in to the fuel injection pump.
Fuel bleed pump	This is a manual fuel pump. Pushing the knob on the top of the fuel filter feeds the fuel. The pump is also used to bleed air from the fuel system.
Engine oil filler port	Filler port for engine oil.
Engine oil filter	Filters fine metal fragments and carbon from the engine oil. Filtered engine oil is distributed to the engine's moving parts. The filter is a cartridge type and should be replaced periodically.
Engine oil dipstick	Gauge stick for checking the engine oil level.
Marine gear oil filler port (if equipped)	Filler port for marine gear lube oil. Located on top of the marine gear case.
Cooling system	There are two cooling systems: coolant and seawater.
Coolant tank Heat exchanger Coolant pump	The tank stores the coolant and is connected to the heat exchanger. Cooling seawater passes through the heat exchanger to cool the coolant by heat exchange. After cooling, the coolant is fed by the coolant pump to the inside of the engine, around the combustion chamber, turbocharger and then returned to the tank.
Filler cap	Located on the top of the coolant tank. It has two pressure regulating valves (release and retraction valves). When the coolant temperature rises, the pressure inside the coolant tank increases causing the release valve in the filler cap to open.
Reservoir	Hot water and steam pass through a rubber hose to the reservoir for cooling. (The filler port and the reservoir are connected by a rubber hose.) When the load is reduced and the coolant temperature falls, the pressure in the coolant tank is lowered, activating the retraction valve in the filler cap. This causes the coolant in the reservoir to return to the coolant tank. This process reduces the consumption of coolant.
Turbocharger	A pressurized intake air feeding device. The exhaust gas turbine is rotated by the exhaust gas and the power is used to rotate the blower. This pressurizes the intake air for sending to the cylinder.
Charge air cooler	This heat exchanger cools the pressurized charging air from the turbocharger with water.
Zinc anode	The metal area of the seawater cooling system is prone to galvanic corrosion. The zinc anode is installed in the various coolers to prevent this. When the zinc anode becomes worn, components in the fresh water cooler, oil cooler, etc. will corrode. Periodic replacement of the zinc anode is necessary.
Nameplates	Nameplates are provided on the engine and have the model, serial number and other data.
Starter	A DC motor for starting the engine. Electric current causes the pinion gear to engage with the ring gear on the flywheel to start the engine.
Alternator	This generator rotates by a V-belt drive to charge the battery during operation.



CONTROL EQUIPMENT

The control equipment at the helm makes remote control operation possible. It consists of the instrument panel, which is connected to the engine by a wire harness, and the remote control (throttle) handle, which is connected by control cables to the engine control lever.

Instrument Panel (Optional)


■ Equipment and functions

The instrument panel has the following gauges and alarm devices.

O: Available -: Not available

	Gauge or switch	New B-type panel See (Figure 4)	New C-type panel See (Figure 5)	New D-type panel See (Figure 6)
	Key (starter) switch	0	0	0
	Engine stop button	0	0	0
Switches	Alarm (buzzer)	0	0	0
	Alarm (buzzer) stop switch	0	0	0
	Backlight switch for gauges	0	0	0
	Battery low charge	0	0	0
	Fresh water (coolant) high temperature	0	0	0
	Engine (lube) oil low pressure	0	0	0
Warning indicators	Fresh water (coolant) level	-	0	0
maicators	Exhaust (cooling seawater flow)	0	0	0
	Fuel filter (water separator)	0	0	0
	Gear oil (6LPA-STZP2 only)	-	0	0
	Tachometer with hourmeter	0	0	0
	Engine (lube) oil pressure gauge	_	0	0
Gauges	Fresh water (coolant) temperature gauge	_	0	0
	Turbocharger boost pressure gauge	_	_	0
Clock	Quartz clock	O (Option)	Option)	0
Indicator	Preheat indicator	(Option)	O (Option)	0

New B-type




- 1 Warning indicator display
- 2 Tachometer
- 3 Alarm stop switch
- 4 Panel illumination switch

- 5 Engine stop button
- 6 Starter (key) switch
- 7 Alarm
- 8 Hourmeter

Figure 4

New C-type




- 1 Engine oil pressure gauge
- 2 Fresh water (coolant) temperature gauge
- 3 Tachometer
- 4 Alarm stop switch
- 5 Panel illumination switch

- 6 Engine stop button
- 7 Start (key) switch
- 8 Alarm
- 9 Hourmeter
- 10 Warning indicator display

Figure 5

New D-type



- 1 Turbocharger boost pressure gauge
- 2 Engine oil pressure gauge
- 3 Fresh water (coolant) temperature gauge
- 4 Tachometer
- 5 Alarm stop switch

- 6 Panel illumination switch
- 7 Engine stop button
- 8 Start (key) switch
- 9 Alarm
- 10-Hourmeter
- 11-Clock
- 12 Warning indicator display

Figure 6

Available alarm switches and meter senders

O: Standard ♦: Optional

			6LPA-STP2, 6LPA-STZP2
	Battery not charging		0
	Fresh water (coolant) temperature too	high	0
	Engine (lube) oil pressure too low		0
Switches	Fresh water (coolant) level too low		♦
	Exhaust (cooling seawater flow) restric	tion	\Diamond
	Gear oil (stern drive models only)		\Diamond
Fuel filter		0	
Tachometer		0	
Fresh water (coolant) temperature			\Diamond
0	Engine (lube) oil pressure		\Diamond
Senders	Boost pressure		\Diamond
	Fresh water (coolant) temperature	For two stations	\Diamond
	Engine (lube) oil pressure		♦

■ Switches and gauges

Switch or gauge	Function	
Starter (key) switch	OFF (2): The key can be inserted or removed from switch. All power is turned off.*1 ON (3): For engine operation. Gauges and alarms are operational. START (4): For starting engine. When key is released after engine starts, key automatically moves to ON position. NOTICE Never hold the key in the START position for longer than 15 seconds or the starter motor will overheat. GLOW (1): For air heater (optional).	
Engine stop button	Press the button to stop the engine by cutting off the fuel flow. Continue to press the button until the engine has stopped. *2	
Warning alarm (buzzer)	The alarm sounds if an abnormality is detected. See Warning devices on page 19.	
Warning indicators	The lamps illuminate when an abnormality is detected. See Warning devices on page 19.	
Alarm (buzzer) stop switch	The switch is used to shut the alarm off temporarily. Turn the alarm (buzzer) OFF when inspecting for cause. Inspect and repair the abnormality immediately.	
Backlight switch	Turns instrument panel backlighting OFF or ON.	
Hourmeter	Shows the total number of operating hours. Can be used as a guide for periodic maintenance checks. The hourmeter is located at the bottom of the tachometer.	
Engine (lube) oil pressure gauge	Shows the engine (lube) oil pressure.	
Fresh water (coolant) temperature gauge	Shows the cooling fresh water temperature.	
Turbocharger boost pressure gauge	Shows the intake air pressure (intake air boost pressure of turbocharger).	
Preheat indicator (if equipped)	Illuminates when the air heater is heating up for easier starting in cold temperatures. Indicator is located in the warning lamp cluster.	

^{*1:} The engine cannot be stopped by the starter (key) switch. Use the engine stop button to turn engine OFF.

^{*2:} Releasing the engine stop button before the engine has stopped rotating will cause the engine to continue to run.

■ Warning devices

When a sensor detects a problem during operation, the indicator on the instrument panel will light and an alarm will sound. Indicators are located on the instrument panel, the alarm is located on the back of the panel. Under normal operating conditions, the indicators are off.

- Alarm (buzzer): If a warning lamp illuminates, the alarm will sound. However, no alarm will sound when the battery charging lamp illuminates.
- Alarm (buzzer) stop switch: When investigating the cause of an alarm, press the alarm (buzzer) stop switch.

A WARNING

The switch is used to shut the alarm off temporarily. Turn the alarm (buzzer) OFF when inspecting for cause. Inspect and repair the abnormality immediately.

 Warning indicators: When operation is normal, the warning indicators are OFF. If an abnormality is detected, the sensor will trigger the appropriate warning indicator to light.



Battery low charge indicator

When the alternator output is too low, the indicator will light. When charging begins, the indicator will turn off. No alarm will sound for low battery charge.



Fresh water (coolant) high temperature indicator and alarm

When the coolant temperature reaches the maximum allowable temperature (95 °C [203 °F] or higher), the indicator will light and the alarm will sound. Continuing operation at temperatures exceeding the maximum limit will result in damage and seizure. Check the load and troubleshoot the fresh water cooling system.



Engine (lube) oil low pressure indicator and alarm

When the engine oil pressure falls below the specified level, the oil pressure sensor will send a signal to the indicator causing it to light and the alarm to sound. Stop operation immediately to avoid damage to the engine. Check the oil level and troubleshoot the lubrication system.



Fresh water (coolant) level indicator and alarm

When the amount of cooling water in the fresh water recovery tank falls below normal, the sensor will send a signal to the indicator causing it to light and the alarm to sound. Stop operation immediately to avoid damage to the engine. Check the water level in the cooling water recovery tank and troubleshoot the cooling system.



Fuel filter (water separator)

When the water level inside the water separator becomes too high, the sensor will send a signal to the indicator causing it to light. Drain the water separator. If operation is continued without draining the water separator, fuel feed to the engine is restricted and may cause damage to the engine or fuel injection pump.



Exhaust (cooling seawater flow) restriction

When the amount of cooling seawater being discharged is too low, the sensor will activate the warning indicator. Stop operation immediately to avoid damage to the engine. Check the seawater cooling system for restriction or damage.



Gear oil level (6LPA-STZP2 only)

When the amount of gear oil falls below normal, the sensor will send a signal to the indicator causing it to light and the alarm to sound. Stop engine immediately to avoid damage to the gear device. Check the oil level in the gear and troubleshoot the gear system.

■ Alarms

Check that indicators and alarms are working normally when the key is turned to ON.

Key switch		$OFF \Rightarrow ON$	START ⇒ ON
Engine		Before starting	Running
Alarm		ON	OFF
	Battery low charge indicator	ON	OFF
	Fresh water (coolant) high temperature indicator	OFF	OFF
	Engine (lube) oil low pressure indicator	ON	OFF
Indicators	Fresh water (coolant) level indicator	OFF	OFF
	Fuel filter (water separator) indicator	OFF	OFF
Exhaust (cooling seawater flow) restriction indicator		ON	OFF
	Gear oil level (6LPA-STZP2 only)	OFF	OFF

■ Key (starter) switch




Figure 7

The GLOW position (1, Figure 7) is the start aid position. Electric current to the air heater (if equipped) is turned on.

The START position (4, **Figure 7**) allows current to the starting motor. When starting the engine, move the key to the START position and release. The key will automatically move to the ON position.

NOTICE

Never hold the key in the START position for longer than 15 seconds or the starter motor will overheat.

When the key is in the OFF position (2, Figure 7) the electric current is off. The key can be inserted or removed in this position.

The ON position (3, Figure 7) allows electrical current to the controls and equipment and allows the engine to keep running. To stop the engine, keep the key switch in the ON position and push the engine stop button. After stopping the engine, turn key to OFF position.

Engine stop button




Figure 8

Push and hold the stop button (1, Figure 8) on the instrument panel to stop the engine. When the stop button is pushed, the solenoid valve on the fuel injection pumps stops the fuel supply to the engine.

Press and hold the engine stop button until the engine has come to a complete stop.

NOTICE

Releasing the engine stop button before the engine has stopped rotating will cause the engine to continue to run.


Remote Control (Throttle) Handle

The engine is controlled by the remote control handle located in the cockpit. The speed control lever on the engine and clutch lever on the marine drive are connected by remote control cables. There are various models of remote control handles available. When using a model other than shown below, consult the manufacturer's documentation for more information.

Morse remote control handle (optional)

This is a single-lever remote control handle connected by a remote cable. It operates the clutch to NEUTRAL, FORWARD and REVERSE and controls the engine speed.


MT-3 top mount



- 1 Reverse high speed
- 2 Reverse low speed
- 3 Reverse
- 4 Neutral
- 5 Forward
- 6 Forward low speed
- 7 Forward high speed

Figure 9

MV side mount



- 1 Forward high speed
- 2 Forward low speed
- 3 Forward
- 4 Neutral
- 5 Reverse
- 6 Reverse low speed
- 7 Reverse high speed

Figure 10

The operation labels on the handle are:

- FWD Forward
- NEU Neutral (clutch disengaged)
- Throttle Position to reduce engine speed
- REV Reverse

Starting and stopping

Put the handle in NEUTRAL. This puts the clutch in the disengaged position and the engine at a low speed.

Forward

Move the handle from NEUTRAL to FWD (forward). This engages the clutch in forward and simultaneously increases the engine speed. Pushing the handle further in the same direction increases engine speed to full speed.

Reverse


Move the handle from NEUTRAL to REV (reverse). This engages the clutch in reverse and simultaneously increases the engine speed. Pushing the handle further in the same direction increases engine speed to full speed.

Free throttle operation

When the boat is stopped (clutch is in NEUTRAL) the idling speed of the engine can be increased in the following manner:

- 1. Ensure the handle is in NEUTRAL.
- 2. Disengage the clutch:


MT-3



- 1 Neutral
- 2 -Low speed
- 3 High speed
- 4 Remote control (throttle) handle

Figure 11

ΜV



- 1 High speed
- 2 -Low speed
- 3 Neutral
- 4 Free throttle button

Figure 12

- 3. MT-3: Pull the throttle handle (4, Figure 11) all the way out.
 - MV: Pull out the free throttle button (4, Figure 12), located next to the handle.

When the handle or button is pulled out, move the handle to either FORWARD or REVERSE to increase the idling speed.

Returning to normal operation

- MT-3: Move the throttle handle to NEUTRAL (1, Figure 11). The lever will automatically return to the normal position.
- MV: Move throttle handle to NEUTRAL (3, Figure 12). Push the free throttle button in.

Page Intentionally Left Blank

BEFORE YOU OPERATE

INTRODUCTION

This section of the Operation Manual describes the diesel fuel, engine oil and engine coolant specifications and how to replenish them.

Safety Precautions

Before performing any operations within this section, review the Safety section on page 3.

DIESEL FUEL

Diesel Fuel Specifications

A WARNING

Fire and Explosion Hazard

Diesel fuel is flammable and explosive under certain conditions.

NOTICE

Only use diesel fuels recommended by Yanmar for the best engine performance, to prevent engine damage. Only use clean diesel fuel.

Diesel fuel should comply with the following specifications. The table lists several worldwide specifications for diesel fuels.

Diesel fuel specification	Location
ASTM D975 No. 2-D, No. 1-D	USA
EN590-2009	European Union
ISO 8217 DMX	International
BS 2869-A1 or A2	United Kingdom
JIS K2204 Grade No. 2	Japan

■ Biodiesel fuels

Yanmar approves the use of biodiesel fuels that do not exceed a blend of 7 % non-mineral oil based fuel with 93 % standard diesel fuel. Such biodiesel fuels are known in the marketplace as B7 biodiesel fuels. B7 biodiesel fuel can reduce particulate matter and the emission of "greenhouse" gases compared to standard diesel fuel

NOTICE

If the B7 biodiesel fuel used does not meet the approved specifications, it will cause abnormal wear of injectors, reduce the life of the engine and it may affect the warranty coverage of your engine.

B7 diesel fuels must meet certain specifications

The biodiesel fuels must meet the minimum specifications for the country in which they are used:

- In Europe, biodiesel fuels must comply with the European Standard EN590-2009, EN14214.
- In the United States, biodiesel fuels must comply with the American Standard ASTM D-6751, D7467.

Biodiesel should be purchased only from recognized and authorized diesel fuel suppliers.



Precautions and concerns regarding the use of biofuels:

- Biodiesel fuels have a higher content of methyl-esters, which may deteriorate certain metal, rubber and plastic components of the fuel system. The customer and/or boat builder are responsible to verify the usage of biodiesel compatible components on the vessel fuel supply and return systems.
- Free water in biodiesel may result in plugging of fuel filters and increased bacterial growth.
- High viscosity at low temperatures may result in fuel delivery problems, injection pump seizures and poor injection nozzle spray atomization.
- Biodiesel may have adverse effects on some elastomers (seal materials) and may result in fuel leakage and dilution of the engine lubricating oil.
- · Even biodiesel fuels that comply with a suitable standard as delivered will require additional care and attention to maintain the quality of the fuel in the equipment or other fuel tanks. It is important to maintain a supply of clean, fresh fuel. Regular flushing of the fuel system, and/or fuel storage containers, may be necessary.
- · The use of biodiesel fuels that do not comply with the standards as agreed to by the diesel engine manufacturers and the diesel fuel injection equipment manufacturers, or biodiesel fuels that have degraded as per the precautions and concerns above, may affect the warranty coverage of your engine.

■ Additional technical fuel requirements

- The fuel cetane number should be 45 or higher.
- The sulfur content must not exceed 0.5 % by volume. Less than 0.05 % is preferred.
- · Never mix kerosene, used engine oil or residual fuels with the diesel fuel.
- Water and sediment in the fuel should not exceed 0.05 % by volume.
- · Keep the fuel tank and fuel-handling equipment clean at all times.
- Ash content not to exceed 0.01 % by volume.
- Carbon residue content not to exceed 0.35 % by volume. Less than 0.1 % is preferred.
- Total aromatics content should not exceed 35 % by volume. Less than 30 % is preferred.
- PAH (Poly cyclic Aromatic Hydrocarbons) content should be below 10 % by volume.
- · Do not use beside.
- Lubricity: Wear mark of WS1.4 should be Max. 0.016 in. (400 µm) at HFRR test.

Handling of Diesel Fuel

A WARNING

Fire and Explosion Hazard

- Only fill the fuel tank with diesel fuel.
 Filling the fuel tank with gasoline may result in a fire and will damage the engine. Never refuel with the engine running. Wipe up all spills immediately. Keep sparks, open flames or any other form of ignition (match, cigarette, static electric source) well away when refueling.
- Always put the diesel fuel container on the ground when transferring the diesel fuel from the pump to the container. Hold the hose nozzle firmly against the side of the container while filling it. This prevents static electricity buildup which could cause sparks and ignite fuel vapors.
- Water and dust in the fuel may cause engine failure. When fuel is stored, be sure that the inside of the storage container is clean and dry, and that the fuel is stored away from dirt or rain.





Figure 1

 Keep the fuel container stationary for several hours to allow any dirt or water to settle to the bottom of the container. Use a pump to extract the clear, filtered fuel from the top of the container.

Fuel Tank (Option)



- 1 Sediment bowl
- 2 Drain cock
- 3 Fuel line to engine


Figure 2

Install a drain cock (2, **Figure 2**) at the bottom of the fuel tank to remove water and contaminants from the sediment bowl (1, **Figure 2**).

The fuel outlet should be positioned 20 to 30 mm (0.75 to 1.125 in.) above the bottom of the tank so that only clean fuel is distributed to the engine.

Fuel System

Install the fuel line from the fuel tank to the fuel injection pump as shown in Figure 3.



- 1 Fuel filter (with priming pump)
- 2 To fuel injection pump
- 3 -Less than 500 mm (20 in.)
- 4 Fuel cock
- 5 20 30 mm (0.75 1.125 in.) Approximately
- 6 Drain cock
- 7 Fuel tank
- 8 Fuel return line

Figure 3

Filling the Fuel Tank

■ Before filling fuel tank for the first time

▲ WARNING

Fire and Explosion Hazard

Never refuel with the engine running.

Rinse fuel tank with kerosene or diesel fuel. Dispose of waste properly.

Filling the fuel tank

WARNING

Fire and Explosion Hazard

- Operate bilge ventilation (blowers) for a minimum of 5 minutes to purge fumes from engine compartment after refueling. Never operate bilge blower while refueling. Doing so can pump explosive fumes into the engine compartment and result in an explosion.
- Hold the hose nozzle firmly against the filler port while filling. This prevents static electricity buildup which could cause sparks and ignite fuel vapors.
- · Never overfill the fuel tank.
- 1. Clean the area around the fuel cap.
- 2. Remove the fuel cap from the fuel tank.
- 3. Fill the tank with clean fuel free of oil and dirt.
- 4. Stop fueling when the gauge shows the fuel tank is full.
- 5. Replace the fuel cap and hand-tighten. Over-tightening the fuel cap will damage it.


Bleeding the Fuel System

A WARNING

Exposure Hazard

Always wear safety glasses when bleeding the fuel system.

Bleeding must be done if any fuel system maintenance has been performed (replacement of fuel filter, etc.) or if the engine does not start after several attempts.



- 1 Priming pump
- 2 Air bleed screw

Figure 4

- Check the fuel level in the fuel tank. Refill if necessary.
- 2. Open the fuel cock of the fuel tank.

- 3. Loosen the air bleed screw (2, **Figure 4**) two to three turns.
- Push up and down on the priming pump (1, Figure 4) to release air out of the air bleed screw.
- 5. Continue pumping until a solid stream of fuel with no air bubbles begins to flow.
- 6. Tighten the air bleed screw.

NOTICE

Never use an engine starting aid such as ether. Engine damage will result.



ENGINE OIL

Engine Oil Specifications

Using engine oil that does not meet or exceed the following guidelines or specifications may cause seizure of parts, abnormal wear and shorten engine life.

Service categories

Use an engine oil that meets or exceeds the following guidelines and classifications:

- · API service categories: CD or higher
- SAE viscosity: 10W30, 15W40 Engine oil 10W30 and 15W40 can be used throughout the year.

NOTICE

- · Be sure the engine oil, engine oil storage containers and engine oil filling equipment are free of sediment or water.
- Change the engine oil after the first 50 hours of operation and then at every 250 hours thereafter.
- Select the oil viscosity based on the ambient temperature where the engine is being operated. See the SAE service grade viscosity chart (Figure 5).
- Yanmar does not recommend the use of engine oil "additives".




Figure 5

Handling engine oil

- 1. When handling and storing engine oil, be careful not to allow dust and water to contaminate the oil. Clean around the filler port before filling.
- 2. Do not mix oils of different types or brands. Mixing may cause the chemical characteristics of the oil to change and lubricating performance to decrease, reducing the engine's life.
- 3. Engine oil should be replaced at the specified intervals, regardless if the engine has been operated.

Engine Oil Viscosity

SAE 10W30 or SAE 15W40 are the recommended oil viscosities.

NOTICE

If you intend to operate your equipment at temperatures outside the limits shown, you must consult your authorized Yanmar Marine dealer or distributor for special lubricants or starting aids.

Checking the Engine Oil




Figure 6

- 1. Make sure the engine is level.
- Remove dipstick (1, Figure 6) and wipe with clean cloth.
- 3. Fully reinsert dipstick.
- Remove dipstick. The oil level should be between upper (2, Figure 6) and lower (3, Figure 6) lines on the dipstick.
- 5. Add oil if necessary. See Adding Engine Oil on page 32.
- 6. Fully reinsert dipstick.

Adding Engine Oil

 Remove the oil filler port cap from filler port (5, Figure 6) and fill with engine oil.

NOTICE

Prevent dirt and debris from contaminating engine oil. Carefully clean the dipstick and the surrounding area before you remove the cap.

2. Fill with engine oil to the upper limit (2, Figure 6) on the dipstick (1, Figure 6).

NOTICE

Never overfill the engine with engine oil.

3. Insert the dipstick fully to check the level.

NOTICE

Always keep the oil level between upper and lower lines on the oil cap/dipstick.

4. Hand-tighten the filler port cap securely.

MARINE DRIVE OIL

Note: Refer to the marine gear manufacturer's operation manual for the marine gear oil specifications. Refer to the manufacturer's operation manual for marine gear or stern drive oil specifications.

Mercruiser® Bravo Stern Drive Oil Specifications

Use marine gear oil that meets or exceeds the following guidelines and classifications:

■ Drive oil

 QuickSilver^{®*1} High Performance Gear Lube

■ Power steering oil (6LPA-STZP2 only)

 QuickSilver® Power Trim and Steering Fluid or Dexlone-II

■ Power trim oil

 QuickSilver® Power Trim and Steering Fluid or SAE 10W-30 or 10W-40 Engine Oil

Checking and Adding Marine Drive Oil

Note: Refer to the manufacturer's operation manual for the proper procedure to check and fill the marine drive oil.

*1: QuickSilver is a registered trademark of Brunswick® Corporation.

Checking and Adding Power Steering Oil (6LPA-STZP2 Models)




Figure 7

- 1. Remove the filler cap/dipstick (3, 4, Figure 7) from the power steering oil service tank (1, Figure 7) and wipe with a clean cloth.
- Fully reinsert dipstick.
- 3. Remove dipstick. The oil level should be between upper (3, Figure 7) and lower (2, Figure 7) lines on the dipstick.
- 4. Fill with oil to the upper limit on the dipstick. See Mercruiser® Bravo Stern Drive Oil Specifications on page 33.

NOTICE

Never overfill the power steering system with oil.

5. Fully reinsert dipstick and tighten.

ENGINE COOLANT

Engine Coolant Specifications

Note: In the U.S., LLC is required for the warranty to be valid.

- Texaco Long Life Coolant (LLC), both standard and premixed, product code 7997 and 7998
- Havoline Extended Life Antifreeze/Coolant, product code 7994

Following the manufacturer's recommendations, use a proper LLC which will not have any adverse effects on the materials (cast iron, aluminum, copper, etc.) of the engine's cooling system.

Always use the mixing ratios specified by the antifreeze manufacturer for the temperature range.

Coolant (Closed Cooling System)

NOTICE

Always add LLC to soft water especially when operating in cold weather. Never use hard water. Water should be clean and free from sludge or particles. Without LLC, cooling performance will decrease due to scale and rust in the coolant system. Water alone may freeze and form ice; it expands approximately 9 % in volume. Use the proper amount of coolant concentrate for the ambient temperature as specified by the LLC manufacturer. LLC concentration should be a minimum of 30 % to a maximum of 60 %. Too much LLC will decrease the cooling efficiency. Excessive use of antifreeze also lowers the cooling efficiency of the engine. Never mix different types or brands of LLC, as a harmful sludge may form. Mixing different brands of antifreeze may cause chemical reactions, and may make the antifreeze useless or cause engine problems.



Checking and Adding Coolant

▲ WARNING

Burn Hazard

Never remove the coolant filler cap if the engine is hot. Steam and hot engine coolant will spray out and seriously burn you. Allow the engine to cool down before you attempt to remove the cap.




Figure 8

- 1. Ensure all drain cocks are closed.
- 2. Loosen the filler cap of the coolant tank to relieve the pressure, then remove the filler cap (1, Figure 8).
- 3. Pour coolant slowly into the coolant tank to avoid air bubbles. Fill until coolant overflows from the filler port.

NOTICE

Never pour cold coolant into a hot engine.

4. Align filler cap tabs with filler port notches and tighten filler cap firmly.

NOTICE

Always tighten reservoir cap securely after checking reservoir. Steam can spray out during engine operation if the cap is loose.

Note: The coolant level rises in the reservoir during operation. After stopping the engine, the coolant will cool down and the extra coolant will return to reservoir.




Figure 9

Check the coolant level in the reservoir. The level should be at the FULL mark (3, Figure 9). Add coolant if necessary.

NOTICE

Never pour cold coolant into a hot engine.

6. Remove reservoir cap (2, Figure 9) to add coolant if necessary. Do not add water.

BEFORE YOU OPERATE

 Replace filler cap and tighten it firmly.
 Failure to do so will cause water leakage.

Reservoir capacity

0.8 L (0.85 qt)

Check the rubber hose (1, Figure 9)
connecting the reservoir to the coolant
tank/heat exchanger. Replace if
damaged.

Note: If the coolant runs low too often or the coolant level in the coolant tank drops without any change in the level in the reservoir, there may be water or air leaks in the cooling system. See your authorized Yanmar dealer or distributor.

CRANKING THE ENGINE

A WARNING



- Never touch or allow your clothes to touch the moving parts of the engine during operation. If a part of your body or clothing is caught in the front drive shaft, V-belt, propeller shaft, etc. serious injury may result.
- Check to see that no tools, pieces of cloth, etc. are left on or around the engine.

NOTICE

When the engine has not been used for a long period of time, engine oil will not be distributed to all of the operating parts. Using the engine in this condition will lead to seizure. After a long period of no use, distribute engine oil to each part by cranking. Perform in accordance with the following procedures before beginning operation.

- 1. Open the seacock.
- 2. Open the fuel cock.
- 3. Put the remote control shift lever in the NEUTRAL See Starting the Engine on page 40.
- 4. Turn on the battery switch (if equipped).




Figure 10

5. Turn key to ON (3, Figure 10). It is normal for the alarm to sound and the warning indicators to light during cranking.

Note: If the engine has not been operated for a long period of time, check that the key can be moved from START to ON positions smoothly.

6. While pushing the STOP button (1, Figure 10), turn the key to the START position (2, Figure 10).

NOTICE

Never hold the key in the START position for longer than 15 seconds or the starter motor will overheat

7. When the key is in the START position, the engine will begin cranking. Continue cranking for about 5 seconds and listen for abnormal noise during that time.

Note: If the STOP button is released during the cranking procedure, the engine will start. Do not start the engine in this mode.

8. Move key to OFF position (4, Figure 10). The engine will stop cranking.

Page Intentionally Left Blank

ENGINE OPERATION

INTRODUCTION

This section of the Operation Manual describes the diesel fuel, engine oil and engine coolant specifications and how to replenish them. It also describes the daily engine checkout.

SAFETY PRECAUTIONS

Before performing any operations within this section, review the Safety section on page 3.

STARTING THE ENGINE

- 1. Open the seacock (if equipped).
- 2. Open the fuel cock.
- Put the remote control handle in NEUTRAL.

Note: Safety equipment should make it impossible to start the engine in any other position than NEUTRAL.

4. Turn the battery master switch (if equipped) to ON.




Figure 1

Turn key switch to ON (3, Figure 1).
 Ensure that the instrument panel indicators light and the alarm sounds.
 This indicates that indicators and alarm are working correctly.

Note: The coolant high temperature alarm indicator does not come on during start-up.

 Turn the key switch to START (4, Figure 1). Release the key switch when the engine has started.

NOTICE

Never hold the key in the START position for longer than 15 seconds or the starter motor will overheat.

The alarm should stop and the indicators should go out.

NOTICE

If any indicator fails to illuminate when the key switch is in the ON position, see your authorized Yanmar Marine dealer or distributor for service before operating the engine.

Note: When the engine has not been used for a long period of time, check that the key can move from the START position to the ON position smoothly.



If the Engine Fails to Start

Before turning the key switch again, be sure to confirm that the engine has stopped completely. If an attempt to restart is made while the engine is running, the pinion gear of the starter motor will be damaged.

NOTICE

- · Never hold for longer than 15 seconds or the starter motor will overheat
- Never attempt to restart the engine if the engine has not stopped completely. Pinion gear and starter motor damage will occur.

Note: Hold the key switch for a maximum of 15 seconds. If the engine does not start the first time, wait for about 15 seconds before trying again.

NOTICE

If the vessel is equipped with a water lift (water lock) muffler, excessive cranking could cause seawater to enter the cylinders and damage the engine. If the engine does not start after cranking for 15 seconds, close the thru-hull water intake valve to avoid filling the muffler with water. Crank for 10 seconds at a time until the engine starts. When the engine does start, stop the engine immediately and turn off the power switch. Be sure to re-open the seacock and restart the engine. Operate the engine normally.

■ Air bleeding the fuel system after starting failure

If the engine does not start after several attempts, there may be air in the fuel system. If air is in the fuel system, fuel cannot reach the fuel injection pump. Bleed the air out of the system. See Bleeding the Fuel System on page 30.

Starting at Low Temperatures

Comply with local environmental requirements. Use engine heaters to avoid starting problems and white smoke. Do not use starting aids.

NOTICE

Never use an engine starting aid such as ether. Engine damage will result.

To limit white smoke, run the engine at low speed and under moderate load until the engine reaches normal operating temperature. A light load on a cold engine provides better combustion and faster engine warm-up than no load.

Avoid running the engine at idling speed any longer than necessary.

■ Starting with air heater (if equipped)

- 1. Open the seacock (if equipped).
- 2. Open the fuel tank cock.
- 3. Put remote control handle in NEUTRAL.
- 4. Turn the battery switch on (if equipped).




Figure 2

5. Turn key switch to GLOW (1, **Figure 2**) for 15 seconds.

NOTICE

Never run the air heater (GLOW position) for more than 20 seconds at a time or engine damage will result.

6. Turn key switch to ON (3, **Figure 2**). Ensure that the instrument panel indicators light and the alarm sounds. This shows that indicators and alarm are working correctly.

Note: The coolant high temperature alarm indicator does not come on during start-up.

Turn key switch to START (4, Figure 2).
Release the key switch when the
engine has started. The alarm should
stop and the indicators should go out.


NOTICE

Never hold the key in the START position for longer than 15 seconds or the starter motor will overheat.

After the Engine has Started

1. After the engine has started, ensure the remote control handle is in NEUTRAL.


MT-3



- 1 Neutral
- 2 -Low speed
- 3 High speed
- 4 Throttle handle

Figure 3

MV



- 1 High speed
- 2 -Low speed
- 3 Neutral
- 4 Free throttle button

Figure 4

- 2. MT-3: Pull out the handle lever (4, Figure 3) and adjust the speed to no more than 1500 min-1 (rpm) and run the engine at low speed with no load.
- 3. MV: Pull out the free throttle button (4, Figure 4) and adjust the speed to no more than 1500 min⁻¹ (rpm) and run the engine at low speed with no load.
- 4. Allow engine to run for approximately 5 minutes.

Check the following items at a low engine speed:

- Check that the gauges, indicators and alarm are normal.
 - Normal coolant operating temperature is approximately 70 to 90 °C (158 to 194°F).
 - Normal oil pressure at 3000 min⁻¹ is 0.34 to 0.54 MPa (48 to 78 psi).
- 2. Check for water, fuel or oil leakage from the engine.
- 3. Check that the smoke color, engine vibration and sound are normal.
- 4. When there are no problems, keep the engine at low speed with the boat still stopped to distribute engine oil to all parts of the engine.
- 5. Check that sufficient cooling water is discharged from the seawater outlet. Operation with inadequate seawater discharge will damage the impeller of the seawater pump. If seawater discharge is too low, stop the engine immediately. Identify the cause and repair.


NOTICE

The engine will seize if it is operated when seawater discharge is too small or if load is applied without any warming up operation.

For troubleshooting assistance, see Troubleshooting after Starting on page 70 or Troubleshooting Chart on page 72. If necessary, see your authorized Yanmar dealer or distributor.

REMOTE CONTROL HANDLE OPERATION


Acceleration and Deceleration MT-3 top mount



- 1 Reverse high speed
- 2 Reverse low speed
- 3 Reverse
- 4 Neutral
- 5 Forward
- 6 Forward low speed
- 7 Forward high speed

Figure 5

MV side mount



- 1 Forward high speed
- 2 Forward low speed
- 3 Forward
- 4 Neutral
- 5 Reverse
- 6 Reverse low speed
- 7 Reverse high speed

Figure 6

Note: Direction of travel will vary depending on installation location.

Use the throttle handle to control acceleration and deceleration. Move the handle slowly and smoothly.

Shifting the Engine

▲ WARNING

Sudden Movement Hazard

The boat will start to move when the marine drive is engaged:

- · Ensure the boat is clear of all obstacles forward and aft.
- Quickly shift to the FORWARD position then back to the NEUTRAL position.
- · Observe whether the boat moves in the direction you expect.

NOTICE

Shifting the marine drive while operating at high speed or not pushing the handle fully into position (partial engagement) will result in damage to marine drive parts and abnormal wear.

- 1. Before using the marine drive, be sure to move the throttle handle to a low idle position (less than 1000 min-1). Move the throttle handle slowly to a higher speed position after completing marine drive engagement.
- 2. When moving the handle between FORWARD (1 to 2, Figure 6) and REVERSE (6 to 7, Figure 6), bring the handle to NEUTRAL (4, Figure 6) and pause before slowly shifting to the desired position. Never shift abruptly from FORWARD to REVERSE or vice versa.

NOTICE

- · Never shift the marine gear at high engine speed. During normal operation, the marine gear should only be shifted with the engine at idle.
- · When sailing, set the remote control handle in NEUTRAL. Not doing so will introduce slippage or any damage and void your warranty.

■ Morse remote control handle (optional)

- Move the handle to the NEUTRAL (middle) position to stop the boat. The engine will idle at low speed.
- · Move the handle to the FORWARD position to go forward. When the clutch is engaged in forward, the speed will decrease.
- Move the handle to the REVERSE position to go in reverse. When the clutch is engaged in reverse, the speed will decrease.

CAUTIONS DURING OPERATION

NOTICE

Engine trouble can arise if the engine is operated for a long time under overloaded conditions with the control handle in the full throttle position (maximum engine speed position), exceeding the continuous rated output engine speed. Operate the engine at about 100 min⁻¹ lower than the full throttle engine speed.

Note: If the engine is in the first 50 hours of operation, see New Engine Break-In on page 10.

Always be on the lookout for problems during engine operation.

Pay particular attention to the following:

 Is sufficient seawater being discharged from the exhaust and seawater outlet pipe?

If the discharge is small, stop the engine immediately; identify the cause and repair.

• Is the smoke color normal?

The continuous emission of black exhaust smoke indicates engine overloading. This shortens the engines life and should be avoided.

Are there abnormal vibrations or noise?

NOTICE

Excessive vibration may cause damage to the engine, marine gear, hull and onboard equipment. In addition, it causes able passenger and crew discomfort.

Depending on the hull structure, engine and hull resonance may suddenly become great at a certain engine speed range, causing heavy vibrations. Avoid operation in this speed range. If you hear any abnormal sounds, stop the engine and inspect.

Alarm buzzer sounds during operation.

NOTICE

If any alarm indicator with audible alarm sound appears on the display during engine operation, stop the engine immediately. Determine the cause and repair the problem before you continue to operate the engine.

• Is there water, oil or fuel leakage, or are there any loose bolts?

Check the engine room periodically for any problems.

 Is there sufficient diesel fuel in the diesel fuel tank?

Replenish diesel fuel before leaving the dock to avoid running out of fuel during operation.

 When operating the engine at low speed for long periods of time, race the engine once every 2 hours.

NOTICE

Racing the engine: With the gear in NEUTRAL, accelerate from the low-speed position to the high-speed position and repeat this process about five times. This is done to clean out carbon from the cylinders and the fuel injection valve. Neglecting to race the engine will result in poor smoke color and reduce engine performance.



• If possible, periodically operate the engine at near maximum engine speed while underway. This will generate higher exhaust temperatures, which will help clean out hard carbon deposits, maintaining engine performance and prolonging the life of the engine.

NOTICE

Never turn off the battery switch (if equipped) or short the battery cables during operation. Damage to the electric system will result.

SHUTTING DOWN THE **ENGINE**

Normal Shutdown

- 1. Reduce engine speed to low idle and put remote control handle in NEUTRAL.
- 2. Accelerate from low speed to high speed and repeat five times. This will clean out the carbon from the cylinders and the fuel injection nozzles.
- 3. Allow engine to run at low speed (approximately 1000 min-1) without load for 5 minutes.

NOTICE

For maximum engine life, Yanmar recommends that when shutting the engine down, you allow the engine to idle, without load, for 5 minutes. This will allow the engine components that operate at high temperatures, such as the turbocharger and exhaust system, to cool slightly before the engine itself is shut down.




Figure 7

4. With the key in the ON position, push and hold the STOP button (1, Figure 7). After the engine has stopped, turn the key switch to OFF.

ENGINE OPERATION

5. Remove the key and cover the key switch with the moisture cap.

NOTICE

Continue to hold the stop button in until the engine is completely stopped. If the button is released before the engine has completely stopped, it may restart. If the engine does not shut off when the engine stop button is pushed, close the fuel cock on the fuel tank.

- 6. Turn off the battery switch (if equipped).
- 7. Close the fuel cock.
- 8. Close the seacock (if equipped).

NOTICE

- Be sure to close the seacock.
 Neglecting to close the seacock could allow water to leak into the boat and may cause it to sink.
- If seawater is left inside the engine, it may freeze and damage parts of the cooling system when the ambient temperature is below 0 °C (32 °F).

CHECKING THE ENGINE AFTER OPERATION

- Check that the power switch is off and that the battery switch (if equipped) is turned to off.
- Fill the fuel tank. See Filling the fuel tank on page 29.
- Close seawater cock(s).
- If there is a risk of freezing, check that the cooling system contains enough coolant. See Engine Oil Specifications on page 31.
- If there is a risk of freezing, drain the seawater system. See Drain Seawater Cooling System on page 76.
- At temperatures below 0 °C (32 °F), drain seawater system and connect the engine heater (if equipped).

PERIODIC MAINTENANCE

INTRODUCTION

This section of the Operation Manual describes the procedures for proper care and maintenance of the engine.

SAFETY PRECAUTIONS

Before performing any maintenance procedures within this section, read the following safety information and review the Safety section on page 3.

PRECAUTIONS

The Importance of Periodic Maintenance

Engine deterioration and wear occur in proportion to the length of time the engine has been in service and the conditions the engine is subjected to during operation. Periodic maintenance prevents unexpected downtime, reduces the number of accidents due to poor machine performance and helps extend the life of the engine.

Performing Periodic Maintenance

A WARNING

Exhaust Hazard

Never block windows, vents, or other means of ventilation if the engine is operating in an enclosed area. All internal combustion engines create carbon monoxide gas during operation. Accumulation of this gas within an enclosure could cause illness or even death. Make sure that all connections are tightened to specifications after repair is made to the exhaust system. Failure to comply could result in death or serious injury.

The Importance of Daily Checks

The Periodic Maintenance Schedule assumes that the daily checks are performed on a regular basis. Make it a habit to perform daily checks before the start of each operating day. See Daily Checks on page 54.

Keep a Log of Engine Hours and Daily Checks

Keep a log of the number of hours the engine is run each day and a log of the daily checks performed. Also note the date, type of repair (e.g., replaced alternator) and parts used for any service needed between the periodic maintenance intervals. Periodic maintenance intervals are every 50, 125, 250, 500, 1000 and 1250 engine hours. Failure to perform periodic maintenance will shorten the life of the engine.

NOTICE

Failure to perform periodic maintenance will shorten the life of the engine and may void the warranty.

Yanmar Replacement Parts

Yanmar recommends that you use genuine Yanmar parts when replacement parts are needed. Genuine replacement parts help ensure long engine life.

Tools Required

Before you start any periodic maintenance procedure, make sure you have the tools you need to perform all of the required tasks

Ask Your Authorized Yanmar Marine Dealer or Distributor for Help

Our professional service technicians have the expertise and skills to help you with any maintenance or service related procedures you need help with.



Tightening Fasteners

Use the correct amount of torque when you tighten fasteners on the engine. Applying excessive torque may damage the fastener or component and not enough torque may cause a leak or component failure.

NOTICE



The tightening torque in the Standard Torque Chart should be applied only to the bolts with a "8.8" head (JIS strength classification: 8.8). Apply 60 % torque to bolts that are not listed. Apply 80 % torque when tightened to aluminum alloy.

Bolt diameter × pitch (mm)	M6 × 1.0	M8 × 1.25	M10 × 1.5	M12 × 1.75	M14 × 1.5	M16 × 1.5
Tightening N·m	11 ± 1.0	25 ± 3	49 ± 5	88 ± 10	140 ± 10	230 ± 10
torque ft-lb	8.0 ± 0.7	18.8 ± 2.2	36.2 ± 3.7	65.1 ± 7.4	103 ± 7.2	170 ± 7.2

Taper plugs	1/8	1/4	3/8	1/2
Tightening N⋅m	10	20	29	59
torque ft-lb	7.4	14.5	21.7	43.2

When lock adhesive is applied, decide separately.

Pipe joint bolts	M8	M10	M12	M14	M16
Tightening N·m	15 ± 2	23 ± 3	29 ± 5	44 ± 5	54 ± 5
torque ft-lb	10.9 ± 1.5	16.6 ± 2.2	21.7 ± 3.7	32.6 ± 3.7	69.8 ± 3.7

PERIODIC MAINTENANCE SCHEDULE

Daily and periodic maintenance is important to keep the engine in good operating condition. The following is a summary of maintenance items by periodic maintenance intervals. Periodic maintenance intervals vary depending on engine application, loads, diesel fuel and engine oil used and are hard to establish definitively. The following should be treated only as a general guideline.

NOTICE

Establish a periodic maintenance plan according to the engine application and make sure to perform the required periodic maintenance at the intervals indicated. Failure to follow these guidelines will impair the engine's safety and performance characteristics, shorten the engine's life and may affect the warranty coverage on your engine.

See your authorized Yanmar Marine dealer or distributor for assistance when checking items marked with a •.

O: Check or Clean ♦: Replace ●: Contact your authorized Yanmar marine dealer or distributor

	Item	Periodic maintenance interval							
System		Daily	Every 50 hours or monthly, whichever comes first	Every 125 hours or 6 months, whichever comes first	Every 250 hours or 1 year, whichever comes first	Every 500 hours or 2 years, whichever comes first	Every 1000 hours or 4 years, whichever comes first	Every 1250 hours or 5 years, whichever comes first	
Whole	Visual inspection of engine exterior	0							
	Check the fuel level and refill if necessary	0							
	Drain water and sediment from fuel tank		0						
	Drain the fuel/water separator		0						
Fuel system	Replace the fuel filter element		♦ Initial 50		♦				
	Check the fuel injection timing						•		
	Check the fuel injector pressure and nozzle spray pattern				Initial 250		•		
	Check the engine oil level	0							
Lubricating	Change the engine oil		♦ Initial 50	\$					
system	Replace the engine oil filter element		♦ Initial 50	\$					
	Wash the engine oil cooler							•	
	Check the marine drive oil	0		•	•		•	•	
Marine drive	Check power steering oil	0	Refer to the marine drive system operation manual						
system	Check power trim oil	0							
	Check drive oil	0	1						

O: Check or Clean ♦: Replace ●: Contact your authorized Yanmar marine dealer or distributor

		Periodic maintenance interval							
System	Item	Daily	Every 50 hours or monthly, whichever comes first	Every 125 hours or 6 months, whichever comes first	Every 250 hours or 1 year, whichever comes first	Every 500 hours or 2 years, whichever comes first	Every 1000 hours or 4 years, whichever comes first	Every 1250 hours or 5 years, whichever comes first	
	Check coolant level	0							
Fresh	Change coolant				♦				
water cooling system	Clean and check the cooling water passage							•	
•	Clean the cooling water system							•	
	Check seawater outlet discharge	O During operation							
Seawater cooling	Check or replace the seawater pump impeller						•		
system	Check or replace the zinc anodes				♦				
	Check and clean the seawater passage							•	
Piping	Clean or replace the exhaust/water mixing elbow					•			
, ping	Check or replace fuel line and rubber hoses	0				•			
	Check the alarm and indicators	0							
Electrical system	Check the electrolyte level in the battery		0						
-	Adjust the tension of the alternator V-belt or replace V-belt					0		•	
Remote control	Check and lubricate the remote control cable operation	0							
handle	Adjust the remote control cable				0				
	Wash turbocharger blower				•				
de la companya de la	Clean air cleaner				0				
Intake and exhaust system	Adjust the intake and exhaust valve clearance				Initial 250		•		
	Lap the intake and exhaust valves						•		
Miscella-	Check and adjust the power steering oil pump belt (6LPA-STZP2)					0			
neous	Replace the timing belt							•	
	Replace the front rubber damper							•	

Note: These procedures are considered normal maintenance and are performed at the owner's expense.

PERIODIC MAINTENANCE PROCEDURES

▲ WARNING

Exposure Hazard

Always wear personal protective equipment when performing periodic maintenance procedures.

Daily Checks

Before you head out for the day, make sure the Yanmar engine is in good operating condition.

NOTICE

It is important to perform the daily checks as listed in this Operation Manual. Periodic maintenance prevents unexpected downtime, reduces the number of accidents due to poor engine performance and helps extend the life of the engine.

Make sure you check the following items.

■ Visual checks

A WARNING

Piercing Hazard

- Avoid skin contact with the high-pressure diesel fuel spray caused by a fuel system leak, such as a broken fuel injection line.
- High-pressure fuel can penetrate your skin and result in serious injury. If you are exposed to high-pressure fuel spray, obtain prompt medical treatment.
- Never check for a fuel leak with your hands.
- Always use a piece of wood or cardboard. Have your authorized Yanmar Marine dealer or distributor repair any damage.
- 1. Check for engine oil leaks.
- 2. Check for fuel leaks.
- 3. Check for engine coolant leaks.
- 4. Check for damaged or missing parts.
- Check for loose, missing or damaged fasteners.
- Check the electrical harnesses for cracks, abrasions, and damaged or corroded connectors.
- 7. Check hoses for cracks, abrasions, and damaged, loose or corroded clamps.

Check the fuel filter/water separator for presence of water and contaminants. If you find any water or contaminants. drain the fuel filter/water separator. See Draining fuel filter/water separator on page 59. If you have to drain the fuel filter/water separator frequently, drain the fuel tank and check for the presence of water in your fuel supply. See Draining water from the fuel tank on page 58.

NOTICE

If any problem is noted during the visual check, the necessary corrective action should be taken before operating the engine.

Check diesel fuel, engine oil and engine coolant levels

Follow the procedures in Diesel Fuel on page 26, Engine Oil on page 31 and Engine Coolant on page 34 to check these levels.

Checking and refilling marine drive oil

See Marine Drive Oil on page 33.

Checking the battery electrolyte level

Check the battery electrolyte level before use. See Checking the battery electrolyte level (serviceable batteries only) on page 59.

Checking the alternator belt

Check the belt tension before use. See Checking and adjusting the alternator V-belt tension on page 64.

Checking the remote control handle

Check the operation of the remote control handle and ensure it moves smoothly. If it is hard to operate, grease the joints of the remote control cable and lever bearings. If the lever is too loose, adjust the remote control cable. See Checking and adjusting remote control cables on page 63.

Checking the alarm indicators

When operating the start switch on the instrument panel, check that there is no alarm message on the display and the alarm indicators work normally. See Control Equipment on page 15.

Preparing fuel, oil and coolant in reserve

Prepare sufficient fuel for the days operation. Always store engine oil and coolant in reserve (for at least one refill) onboard, to be ready for emergencies.

After Initial 50 Hours of Operation

Perform the following maintenance after the initial 50 hours of operation.

- Changing the engine oil and replacing the engine oil filter element
- · Changing the fuel filter element
- Changing the engine oil and replacing the engine oil filter element

The engine oil on a new engine becomes contaminated from the initial break-in of internal parts. It is very important that the initial oil replacement is performed as scheduled.

It is easiest and most effective to drain the engine oil after operation while the engine is still warm.

A WARNING

If you must drain the engine oil while it is still hot, stay clear of the hot engine oil to avoid being burned. Always wear eye protection.




Figure 1

- 1. Turn the engine OFF.
- 2. Remove the engine oil dipstick. Attach the oil drain pump (if equipped) and pump out the oil.

For easier draining, remove the engine oil fill cap.

NOTICE

Prevent dirt and debris from contaminating engine oil. Carefully clean the dipstick and the surrounding area before you remove the dipstick.

- 3. Turn the engine oil filter (1, **Figure 1**) counterclockwise with a wrench.
- 4. Remove the engine oil filter.
- 5. Apply a small amount of engine oil to the seal of the new filter.
- 6. Install a new filter element and tighten by hand until the seal touches the housing.
- 7. Turn filter an additional 3/4 turn with a filter wrench.





Figure 2

8. Remove filler cap (1, **Figure 2**) and fill with new engine oil through filler port. See Engine Oil on page 31.

NOTICE

- · Never mix different types of engine oil. This may adversely affect the lubricating properties of the engine oil.
- · Never overfill. Overfilling may result in white exhaust smoke, engine overspeed or internal damage.
- 9. Perform a trial run and check for oil leaks.
- 10. Approximately 10 minutes after stopping the engine, remove the oil dipstick and check the oil level. Add oil if the level is too low.
- 11. Dispose of waste properly.

■ Replacing the fuel filter element



- 1 Mounting screw (2 used)
- 2 Housing
- 3 Alarm switch
- 4 O-ring
- 5 Filter element

Figure 3

PERIODIC MAINTENANCE

- 1. Close the fuel cock of the fuel tank.
- 2. Remove the two mounting screws (1, Figure 3) and the housing (2, Figure 3).
- Drain the fuel from the fuel drain cock on the bottom of the fuel/water separator.
- 4. Disconnect the alarm switch harness.




Figure 4

- 5. Remove the alarm switch (3, **Figure 3**) with a wrench.
- 6. Remove the filter element (5, **Figure 3**) with a filter wrench.
- 7. Install the alarm switch to the new fuel filter.


Component	Part No.		
Fuel filter element	119773-55710		

- 8. Apply a thin film of clean diesel fuel to the sealing surface of the new filter gasket.
- 9. Install new filter and tighten hand-tight. Use a filter wrench and tighten to 14.7 19.6 N·m (130.1 173.5 in.-lb).
- 10. Install filter and tighten hand-tight.
- 11. Connect the alarm switch harness.
- 12.Install the housing and mounting screws.
- 13. Bleed the fuel system. See Bleeding the Fuel System on page 30. Dispose of waste properly.
- 14. Start engine and check for leaks.

Every 50 Hours of Operation

After you complete the initial 50 hour maintenance procedures, perform the following procedures every 50 hours thereafter or monthly, whichever comes first.

- · Draining water from the fuel tank
- · Draining fuel filter/water separator
- Checking battery electrolyte level
- Draining water from the fuel tank



- 1 Sediment bowl
- 2 Drain cock
- 3 Fuel line to engine

Figure 5

- 1. Put a pan under the drain cock (2, Figure 5) to catch fuel.
- 2. Open the drain cock and drain water and sediment. Close the drain cock when the fuel is clean and free of air bubbles.

NOTICE

Dispose of waste properly.



■ Draining fuel filter/water separator

Water and sediment can clog the fuel filter and impair the function of the fuel injection pump and valve. If heavy deposits of water and sediment are drained, also drain the fuel tank.




Figure 6

- 1. Close the fuel cock of the fuel tank.
- 2. Remove the two mounting screws (1. Figure 6) and remove the housing (2, Figure 6).
- 3. Put a pan under the drain cock.
- 4. Loosen the drain cock of the water separator and drain off any water or dirt collected inside.
- 5. Install housing and mounting screws.
- 6. Bleed air from the fuel system. See Bleeding the Fuel System on page 30.

■ Checking the battery electrolyte level (serviceable batteries only)

WARNING

- · Batteries contain sulfuric acid. Never allow battery fluid to come in contact with clothing, skin or eyes. Severe burns could result. Always wear safety goggles and protective clothing when servicing the battery. If battery fluid contacts the eyes and/or skin, immediately flush the affected area with a large amount of clean water and obtain prompt medical treatment.
- If operation continues with insufficient battery fluid, the battery life is shortened, and the battery may overheat and explode.

NOTICE

Never turn off the battery switch (if equipped) or short the battery cables during operation. Damage to the electric system will result.

Note: Battery fluid tends to evaporate in high temperatures, especially in summer. In such conditions, inspect the battery earlier than specified.

- 1. Turn the battery master switch to OFF (if equipped) or disconnect the negative (-) battery cable.
- 2. Do not operate with insufficient battery electrolyte as the battery will be destroyed.
- 3. Remove the plugs and check the electrolyte level in all cells.

NOTICE

Never attempt to remove the covers or fill a maintenance-free battery.

 If the level is lower than the minimum fill level (1, Figure 7), fill with distilled water (2, Figure 7) (available in the grocery store) up to the upper limit (3, Figure 7) of the battery.




Figure 7

K0004566

Every 125 Hours of Operation

Perform the following maintenance every 125 hours of operation or 6 months, whichever comes first.

- Changing the engine oil and replacing the engine oil filter
- Changing the engine oil and replacing the engine oil filter

See Changing the engine oil and replacing the engine oil filter element on page 56.

After Initial 250 Hours of Operation

Perform the following maintenance after the initial 250 hours of operation.

- Checking the fuel injector spray pattern
- Inspecting and adjusting intake/exhaust valve clearance
- Checking the fuel injector spray pattern

See your authorized Yanmar Marine dealer or distributor.

Inspecting and adjusting intake/exhaust valve clearance

Proper adjustment is necessary to maintain the correct timing for opening and closing the valves. Improper adjustment will cause the engine to run noisily, resulting in poor engine performance and engine damage. See your authorized Yanmar Marine dealer or distributor to adjust the intake/exhaust valve clearance.

Every 250 Hours of Operation

Perform the following maintenance every 250 hours or one year of operation, whichever comes first.

- Replacing the fuel filter element
- Changing the coolant
- · Checking or replacing the zinc anodes
- Adjusting the remote control cable
- Cleaning the turbocharger
- Cleaning the air cleaner
- Replacing the fuel filter element

See Replacing the fuel filter element on page 57.

Changing the coolant

Replace the coolant every year.

Note: If Long Life coolant is used, replace coolant every 2 years.

- 1. Drain the fresh water cooling system. See Drain Seawater Cooling System on page 76.
- 2. Fill the cooling system with clean coolant. See Checking and Adding Coolant on page 35.

Checking or replacing zinc anodes

Inspect and replace the zinc anodes periodically.

NOTICE

If zinc anodes are not replaced periodically, corrosion and engine damage will result.

PERIODIC MAINTENANCE

- 1. Close the seacock.
- 2. Drain the seawater cooling system. See Drain Seawater Cooling System on page 76.




Figure 8

- 3. Remove all the plugs (1, Figure 9), (3, Figure 10), (4, Figure 11), (2, Figure 12) and (2, Figure 13) labeled ZINC (1, Figure 8).
- 4. Measure the remaining zinc in the plug. Replace the zinc anode when it is less than one-half its original size. See chart for sizes.
- 5. Install a new zinc in a new plug.

NOTICE

Never use sealing tape to install the zinc anode. The anode must make metal-to-metal contact.

- 6. Install plug.
- 7. Open the seacock and check for leaks.

Fuel cooler




Figure 9

Fresh water cooler




Figure 10 Intercooler




Figure 11 **Engine oil cooler**




Figure 12

Engine oil cooler




Figure 13

Location	Part No.	Qty.	Dimensions D × L
Fuel cooler	119574-44150	1	0.5 × 1.0 in.
Engine oil cooler	119574-44150	2	0.5 × 1.0 in.
Fresh water cooler	119574-44150	2	0.5 × 1.0 in.
Inter-cooler	119574-18790	1	0.5 × 1.0 in.

Note: Some marine drives have additional zinc anodes. Check the manufacturer's documentation for location and other information.

■ Checking and adjusting remote control cables

Note: Never adjust the high speed stop bolt on the governor. This will void the engine warranty.

Adjusting engine speed (governor) remote control cable

See your authorized Yanmar dealer or distributor.

Adjusting clutch remote control cable

Refer to the manufacturer's documentation.

Cleaning the turbocharger

Contamination of the turbocharger causes revolutions to drop and engine output to fall.

If a significant drop in engine output is noted (10 % or more), clean the turbocharger.

This should be done only by a trained and qualified technician. See your authorized Yanmar Marine dealer or distributor.

Cleaning the air cleaner




Figure 14

- 1. Slide air cleaner (1, Figure 14) off air inlet.
- 2. Clean the air cleaner with detergent.
- 3. Allow to air dry and install on the air inlet.

NOTICE

Replace the air cleaner if unable to clean or if damaged.

Every 500 Hours of Operation

Perform the following maintenance every 500 hours or 2 years of operation, whichever comes first.

- Cleaning or replacing exhaust/water mixing elbow
- · Replacing fuel line and rubber hoses
- Adjusting or replacing the alternator V-belt
- Checking and adjusting the power steering oil pump belt (6LPA-STZP2 models)
- Cleaning or replacing exhaust/water mixing elbow

See your authorized Yanmar dealer or distributor.

Replacing fuel line and rubber hoses

Replace fuel line and rubber hoses every 500 hours or 2 years, whichever comes first.

See your authorized Yanmar Marine dealer or distributor.

■ Checking and adjusting the alternator V-belt tension




Figure 15

NOTICE

Never get any oil on the belt(s). Oil on the belt causes slipping and stretching. Replace the belt if it is damaged.

Never over-tighten the belt(s). Engine damage will result.

- 1. Check the belt by pushing on the middle of the belt (1, **Figure 15**) with your finger.
 - With proper tension, the belt should deflect 8 10 mm (approximately 3/8 in.).
- Loosen the alternator bolt (2, Figure 15) and move the alternator to adjust the V-belt tension.
- 3. Replace the V-belt if required.

Alternator V-belt Part No.

119775-77260

Checking and adjusting the power steering oil pump belt (6LPA-STZP2 models)

NOTICE

Never get any oil on the belt(s). Oil on the belt causes slipping and stretching. Replace the belt if it is damaged.

Never over-tighten the belt(s). Engine damage will result.




Figure 16

1. Check the belt by pushing on the middle of the belt (3, Figure 16) with your finger.

With proper tension, the belt should deflect 8 - 10 mm (approximately 3/8 in.) (4, Figure 16).

- 2. Loosen the power steering pump bolt (2, Figure 16) and move the oil pump (1, Figure 16) to adjust the belt tension.
- 3. Replace the belt if required.

Power steering oil pump belt Part No. (6LPA-STZP2 only) 119787-26540

Every 1000 Hours of Operation

Perform the following maintenance every 1000 hours or 4 years of operation, whichever comes first.


- Checking the fuel injection timing
- Checking the fuel injector pressure and nozzle spray pattern
- Replacing the seawater pump impeller
- Adjusting intake/exhaust valve clearance
- Lapping the intake and exhaust valves
- Checking the fuel injection timing

See your authorized Yanmar Marine dealer or distributor.

■ Checking the fuel injector pressure and nozzle spray pattern

See your authorized Yanmar Marine dealer or distributor.

Checking or replacing seawater pump impeller



- 1 Impeller
- 2 O-ring
- 3 Cover
- 4 Cover bolts

Figure 17

PERIODIC MAINTENANCE

- 1. Close the seacock.
- 2. Drain the seawater cooling system. See Drain Seawater Cooling System on page 76.
- 3. Loosen the cover bolts and remove the cover and O-ring.
- 4. Inspect the inside of the seawater pump with a flashlight. If any of the following are found, disassembly and maintenance are required:
 - Impeller blades are cracked or nicked.
 Edges or surfaces of the blades are marred or scratched.
 - · Wear plate is damaged.
- If no damage is found when inspecting the inside of the pump, install the O-ring and cover.
- If a large amount of water leaks continuously from the water drain line below the seawater pump during operation, replace the mechanical seal. See your authorized Yanmar Marine dealer or distributor.
- When replacement is required, see your authorized Yanmar Marine dealer or distributor.

NOTICE

Replace the seawater pump impeller every 1000 hours even if no damage is apparent.

Adjusting intake/exhaust valve clearance

See your authorized Yanmar Marine dealer or distributor.

■ Lapping the intake and exhaust valve

See your authorized Yanmar Marine dealer or distributor.

Every 1250 Hours of Operation

Perform the following maintenance procedures every 1250 hours of operation or 5 years, whichever comes first.

- · Cleaning the cooling water system
- Cleaning and checking the seawater passage
- Cleaning and checking the fresh water cooling water passage
- Adjusting the tension of the alternator V-belt
- · Replacing the timing belt
- · Washing engine oil cooler
- Replacing the front rubber damper
- Cleaning the cooling water system

See your authorized Yanmar Marine dealer or distributor.

■ Cleaning and checking the seawater passage

See your authorized Yanmar Marine dealer or distributor.

■ Cleaning and checking the fresh water cooling water passage

See your authorized Yanmar Marine dealer or distributor.

Adjusting the tension of the alternator V-belt

See Checking and adjusting the alternator V-belt tension on page 64.

■ Replacing the timing belt

See your authorized Yanmar Marine dealer or distributor

■ Washing the engine cooler

See your authorized Yanmar Marine dealer or distributor.

■ Replacing the front rubber damper

See your authorized Yanmar Marine dealer or distributor.

Page Intentionally Left Blank

TROUBLESHOOTING

SAFETY PRECAUTIONS

Before performing any troubleshooting procedures within this section, review the Safety section on page 3.

If a problem occurs, stop the engine immediately. Refer to the Symptom column in the Troubleshooting Chart to identify the problem.

TROUBLESHOOTING AFTER STARTING

Just after the engine has started, check the following items at a low engine speed:

Is sufficient water being discharged from the seawater outlet pipe?

If the discharge is low, stop the engine immediately. Identify the cause and repair.

Is the smoke color normal?

The continuous emission of black exhaust smoke indicates engine overloading. This shortens the engines life and should be avoided.

Are there abnormal vibrations or noise?

Depending on the hull structure, engine and hull resonance may suddenly increase at certain engine speed ranges, causing heavy vibrations. Avoid operation in this speed range. If any abnormal sounds are heard, stop the engine and inspect for cause.

Alarm sounds during operation.

If the alarm sounds during operation, lower the engine speed immediately, check the alarm lamps and stop the engine for repairs.

Is there water, oil or fuel leakage? Are there any loose bolts or connections?

Check the engine room daily for any leaks or loose connections.

Is there sufficient fuel in the fuel tank?

Refill fuel in advance to avoid running out of fuel. If the tank runs out of fuel, bleed the fuel system. See Bleeding the Fuel System on page 30.

When operating the engine at low speed for long periods of time, race the engine once every 2 hours. Racing the engine with the clutch in NEUTRAL, accelerate from the low-speed position to the high-speed position and repeat this process about five times. This is done to clean out carbon from the cylinders and the fuel injection valves.

NOTICE

Neglecting to race the engine will result in poor smoke color and reduce engine performance.

Periodically operate the engine near maximum speed while underway. This will generate higher exhaust temperatures, which will help clean out hard carbon deposits, maintain engine performance and prolong the life of the engine.



TROUBLESHOOTING INFORMATION


If the engine does not operate properly, refer to the Troubleshooting Chart on page 72 or see your authorized Yanmar Marine dealer or distributor.

Supply the authorized Yanmar Marine dealer or distributor with the following information:

- · Model name and serial number of your engine
- Boat model, hull material, size (tons)
- Use, type of boating, number of hours run
- Total number of operation hours (refer to hourmeter), age of boat
- The operating conditions when the problem occurs:
 - Engine speed (min⁻¹)
 - · Color of smoke
 - Type of diesel fuel
 - Type of engine oil
 - Any abnormal noises or vibration
 - Operating environment such as high altitude or extreme ambient temperatures, etc.
 - Engine maintenance history and previous problems
 - Other factors that contribute to the problem

TROUBLESHOOTING CHART

Symptom	Probable cause	Measure	Reference	
Indicators light on the instrument panel and alarm sounds during operation	Shift to low speed operation immediately, and check which indicator has come on. Stop the engine and inspect. If no abnormality is identified and there is no problem with operation, return to port at lowest speed and request repairs.			
Engine oil low pressure alarm indicator comes	Engine oil level is low.	Check engine oil level. Add or replace.	See Adding Engine Oil on page 32.	
on	Engine oil filter clogged.	Replace engine oil filter. Replace engine oil.	See Changing the engine oil and replacing the engine oil filter element on page 56.	
Fresh water (coolant) level alarm comes on	Coolant/fresh water in coolant recovery tank is low.	Check coolant level and refill.	See Checking and Adding Coolant on page 35.	
Fresh water (coolant) high temperature alarm comes on	Coolant/fresh water in coolant recovery tank is low.	Check coolant level and refill.	See Checking and Adding Coolant on page 35.	
	Leakage in fresh water cooling system causing temperature to rise.	See your authorized Yanmar Marine dealer or distributor.	-	
	Contamination inside cooling system.	See your authorized Yanmar Marine dealer or distributor.	_	
	Fresh water cooling pump damaged.	See your authorized Yanmar Marine dealer or distributor.	-	
Gear oil alarm comes on	Insufficient drive oil.	Check oil level and refill.	See Marine Drive Oil on page 33.	
Fuel filter alarm comes on	Water level in fuel/water separator too high.	Drain.	See Draining fuel filter/water separator on page 59.	
Exhaust alarm comes on	Insufficient discharge of cooling seawater. Check that seacock is open. Damaged seawater pump.	See your authorized Yanmar Marine dealer or distributor.	-	
Faulty warning devices	Do not operate the engine if alarm devices are not repaired. Serious accidents may result if abnormalities are not identified due to faulty indicators or alarm.			



TROUBLESHOOTING

Symptom	Probable cause	Measure	Reference
Indicators do not go on:			
When key is turned ON When any trouble occurs (oil pressure etc.)	No electrical current available. Circuit broken or lamp burned out.	See your authorized Yanmar Marine dealer or distributor.	-
One of the indicators does not go out	Sensor switch is faulty.	See your authorized Yanmar Marine dealer or distributor.	-
Battery low charge indicator does not go out during operation	V-belt is loose or broken.	Replace V-belt or adjust tension.	See Checking and adjusting the alternator V-belt tension on page 64.
	Battery is defective.	Check battery fluid level, specific gravity or replace battery.	See Checking the battery electrolyte level on page 55.
	Alternator power generation failure.	See your authorized Yanmar Marine dealer or distributor.	-
Starting failures:			
Starter turns but engine does not start	No fuel.	Add fuel. Bleed fuel system.	See Filling the Fuel Tank on page 29 and See Bleeding the Fuel System on page 30.
	Air in fuel line.	Bleed fuel system.	See Bleeding the Fuel System on page 30.
	Fuel filter is clogged.	Replace filter element.	See Replacing the fuel filter element on page 61.
	Improper fuel.	Replace with recommended fuel.	See Diesel Fuel Specifications on page 26.
	Problem with fuel injection.	See your authorized Yanmar Marine dealer or distributor.	-
	Compression leakage from intake/exhaust valve.	See your authorized Yanmar Marine dealer or distributor.	-
Starter does not turn or turns slowly (engine	Faulty clutch position.	Shift to NEUTRAL and start.	_
can be turned manually)	Insufficient battery charge.	Check fluid level. Recharge. Replace.	See Checking the battery electrolyte level on page 55.
	Cable terminal contact failure.	Remove corrosion from terminals. Tighten battery cables.	-
	Faulty safety switch device.	See your authorized Yanmar Marine dealer or distributor.	-
	Faulty starter switch.	See your authorized Yanmar Marine dealer or distributor.	-
	Power lacking due to accessory drive being engaged.	See your authorized Yanmar Marine dealer or distributor.	_
Engine cannot be turned manually	Internal parts seized.	See your authorized Yanmar Marine dealer or distributor.	-

TROUBLESHOOTING

Symptom	Probable cause	Measure	Reference			
Abnormal exhaust color:						
Black smoke	Overload	Reduce load.	_			
	Improper propeller matching.	See your authorized Yanmar Marine dealer or distributor.	-			
	Dirty air cleaner.	Clean air cleaner.	See Cleaning the air cleaner on page 63.			
	Improper fuel.	Replace with recommended fuel.	See Diesel Fuel Specifications on page 26.			
	Faulty spraying of fuel injector.	See your authorized Yanmar Marine dealer or distributor.	-			
	Low boost pressure.	See your authorized Yanmar Marine dealer or distributor.	-			
	Incorrect intake/exhaust valve clearance.	See your authorized Yanmar Marine dealer or distributor.	-			
White smoke	Improper fuel.	Replace with recommended fuel.	See Diesel Fuel Specifications on page 26.			
	Faulty spraying of fuel injector.	See your authorized Yanmar Marine dealer or distributor.	-			
	Fuel injection timing off.	See your authorized Yanmar Marine dealer or distributor.	-			
	Engine burning oil (excessive consumption).	See your authorized Yanmar Marine dealer or distributor.	-			

LONG-TERM STORAGE

If the engine will not be used for an extended period of time, special measures should be taken to protect the cooling system, fuel system and combustion chamber from corrosion and the exterior from rusting.

The engine can normally stand idle for up to 6 months. If it remains unused for longer than this, please contact your authorized Yanmar Marine dealer or distributor.

Before performing any storage procedures within this section, review the Safety section on page 3.

In cold temperatures or before long-term storage, be sure to drain the seawater from the cooling system.

NOTICE

- Do not drain the coolant system. A full coolant system will prevent corrosion and frost damage.
- · If seawater is left inside of the engine, it may freeze and damage parts of the cooling system when the ambient temperature is below 0 °C (32 °F).

PREPARE ENGINE FOR LONG-TERM STORAGE

Note: If the engine is close to a periodic maintenance interval, perform those maintenance procedures before putting the engine into long-term storage.

- 1. Wipe off any dust or oil from the outside of engine.
- 2. Drain water from fuel filters.
- 3. Drain fuel tank completely or fill the tank to prevent condensation.
- 4. Grease the exposed areas and joints of the remote control cables and the bearings of the remote control handle.
- 5. Seal the intake silencer, exhaust pipe, etc. to prevent moisture or contamination from entering engine.
- 6. Completely drain bilge in hull bottom.
- 7. Waterproof the engine room to prevent rain or seawater from entering.
- 8. Charge the battery once a month to compensate for battery's self-discharge.
- 9. Remove key from key switch and cover the key switch with moisture cap.

DRAIN SEAWATER COOLING SYSTEM




Figure 1




Figure 2





Figure 3



- 1 Seawater drain cock
- 2 Fresh water drain cock
- 3 Fresh water drain cock
- 4 Seawater pump cover
- 5 Seawater drain cock

Figure 4

NOTICE

If seawater is left inside, it may freeze and damage parts of the cooling system (heat exchanger, seawater pump, etc.) when ambient temperature is below 32 °F (0 °C).

- 1. Close the seacock.
- 2. Open the seawater drain cocks and drain off the seawater.
- 3. Remove four bolts attaching the side cover of the seawater pump. Remove the cover and drain the seawater.
- 4. Install cover and tighten bolts.
- Close all the drain cocks.

RETURNING THE ENGINE TO SERVICE

- 1. Replace the oil and the oil filter before running the engine.
- 2. Supply fuel if the fuel in the fuel tank was removed, and prime the fuel system.
- 3. Confirm that there is engine coolant in the engine.
- 4. Operate the engine at idle speed for 1 minute.
- 5. Check fluid levels and check engine for leaks.

This Page Intentionally Left Blank

SPECIFICATIONS

PRINCIPAL ENGINE SPECIFICATIONS

Specifica	tion	6LPA-STP2	6LPA-STZP2		
Туре		Vertical water-cooled 4-cycle diesel engine			
Number of cylinders		6			
Bore × stroke			94 mm × 100 mm (3.7 in. × 3.94 in.)		
Displacement		4.164 L			
Continuous power at o	rankshaft	211 kW (286 hp)	/3682 min ⁻¹ (rpm)		
Maximum output rating	g*1	232 kW (315 hp)/3	3800 min ⁻¹ (rpm)* ¹		
High idle		4280 ± 25	min ⁻¹ (rpm)		
Low idle		750 + 25/0			
Combustion system		Direct injection			
Starting system		Electric start (12 V - 2.5 kW)			
Charging system		Alternator with built-in regulator 12 V DC - 80 A			
Direction of rotation		Counterclockwise (viewed from flywheel)			
Cooling system		Constant high temperature fresh water cooling (2 systems: seawater and fresh water cooling)			
Cooling water capacity		13.5 L (14.3 qt) engine 1.6 L (1.7 qt) coolant recovery tank			
Lubrication system		Forced lubrication system with trochoid gear pump			
Engine (lube) oil capacity	Total	10.5 L (11.0 qt)			
	Oil pan	8.4 L (8.9 qt)			
Turboohorgor	Model	RHE62W (IHI made)			
Turbocharger	Туре	Water-cooled turbine housing			

SPECIFICATIONS

Specification		6LPA-STP2	6LPA-STZP2	
Dimensions (less gear) L × W × H		1065 × 671 × 729 mm (41.9 × 26.4 × 28.7 in.)	1145 × 752 × 799 mm (45.1 × 29.6 × 31.5 in.)	
Weight (less gear)		408 kg (899 lb)	428 kg (944 lb)	
Recommended battery capacity		12 V × 120 Ah		
Recommended remote control handle		Single-lever-type only		
Engine installation		Flexible engine mount		

^{* 1:} Density of fuel: 0.840 g/cm³ at 15 °C at the inlet of the fuel injection pump. Rating condition: ISO 3046-1, 8665.

Note: 1 *hp metric* = 0.7355 *kW*

■ Output power

	Fuel tem	perature
Specific gravity	25 °C (77 °F)	40 °C (104 °F)
0.860	323	306
0.840	315	299

Marine Drive Specifications (Optional)

	Hurth		Kanzaki			Mercruiser	
Model	ZF63A1	КМН50А	KMH50V	ZT370	Bravo X-1	Bravo X-2	Bravo X-3
Type	8° down	hydraulic	12° down hydraulic		Stern	drive	
Applicable engine	6LPA-STP2		6LPA-STZP2				
Reduction ratio	1.22/1.21	1.67/1.67	1.22/1.22	1.65	1.36	1.50	1.36
ZF63A1: Ahead/Astern	1.56/1.58	2.13/2.13	1.58/1.58	1.78	1.50	1.65	1.50
Bravo X-1, 2, 3:	2.04/2.10	2.43/2.43	2.08/2.08	_	_	1.81	1.65
Both Ahead/Astern	2.52/2.53	_	2.47/2.47	_	-	2.00	1.81

See manufacturer's documentation for additional information.



SYSTEM DIAGRAMS

PIPING DIAGRAMS

Notation	Description
	Screw joint (union)
	Flange joint
-T-	Eye joint
─	Insertion joint
	Drilled hole
	Coolant piping
	Cooling seawater piping
	Lubricating oil piping
	Diesel fuel piping

Note: Fuel rubber pipes (marked *) satisfy EN/ISO7840.

■ 6LPA-STP2




Figure 1

- 1 Heat exchanger
- 2 Exhaust manifold
- 3 Mixing elbow
- 4 Seawater outlet
- 5 Turbocharger
- 6 Fuel injection valves
- 7 Engine oil cooler
- 8 Charge air cooler
- 9 Engine oil filter
- 10 Fuel injection pump
- 11 Seawater inlet (from seacock)
- 12 Seawater pump
- 13-Fuel return pipe (to fuel tank)
- 14 Diesel fuel cooler
- 15 Diesel fuel inlet (from fuel tank)
- 16-Diesel fuel filter
- 17 Coolant temperature sender (optional)
- 18 Coolant temperature switch
- 19 Coolant outlet to heater
- 20 Engine oil cooler relief valves
- 21 Safety valve
- 22 Coolant pump
- 23 Engine oil pump
- 24 Engine oil inlet filter
- 25 Coolant inlet from heater
- 26 Thermostat

■ 6LPA-STZP2




Figure 2

- 1 Power steering oil pump
- 2 Power steering oil tank
- 3 Heat exchanger
- 4 Exhaust manifold
- 5 Mixing elbow
- 6 Seawater outlet
- 7 Turbocharger
- 8 Fuel injection valves
- 9 Power steering cylinder unit (local supply)
- 10 Intercooler
- 11 Engine oil filter
- 12 Power steering oil cooler
- 13-Fuel injection pump
- 14-Seawater inlet (from seacock)
- 15 Seawater pump
- 16 Diesel fuel return pipe (to fuel tank)
- 17 Diesel fuel cooler
- 18 Diesel fuel inlet (from fuel tank)
- 19 Diesel fuel filter
- 20 Coolant temperature sender (optional)
- 21 Coolant temperature switch
- 22 Coolant outlet to heater
- 23 Engine oil cooler relief valves
- 24 Safety valve
- 25 Coolant pump
- 26 Engine oil pump
- 27 Engine oil inlet filter
- 28-Coolant inlet from heater
- 29 Thermostat

This Page Intentionally Left Blank

WIRING DIAGRAMS

Allowable length by cross sectional area of battery cable				
Section of cable Allowable lengt mm² (in.²) L = 1 + 2 + 3 m (f				
15 (0.023)	< 0.86 (0.26)			
20 (0.031)	< 1.3 (0.40)			
30 (0.046)	< 2.3 (0.70)			
40 (0.062)	< 2.8 (0.85)			
50 (0.077)	< 3.5 (1.07)			
60 (0.093)	< 4.1 (1.25)			

■ B-type instrument panel




Figure 3

- 1 Relay
- 2 Engine stop solenoid
- 3 Seawater flow switch
- 4 Grouping (option)
- 5 Coolant temperature switch
- 6 Relay
- 7 Engine oil pressure switch
- 8 Procured by customer
 - 1 + 2 + 3 < 2.5 m 20 mm²
 - $1 + 2 + 3 < 5 \text{ m} 40 \text{ mm}^2$ (cross sectional area)
- 9 Battery switch
- 10 Starter relay
- 11 Starter
- 12 Alternator
- 13-Ground
- 14 Coolant temperature sender
- 15 Tachometer sensor
- 16 Engine oil pressure sensor
- 17 Timer controller (seawater flow switch)
- 18 Boost sender
- 19 Coolant level switch
- 20 Timer controller (coolant level switch)
- 21 Fuel filter switch
- 22 Boost switch
- 23-Wire harness (option)
- 24 Starter switch
- 25 Instrument panel
- 26 Fuel filter
- 27 Boost
- 28 Exhaust
- 29 Coolant temperature
- 30 Engine oil pressure
- 31 Charge
- 32 Output status table
- 33 Tachometer with hourmeter
- 34 Buzzer
- 35 Buzzer stop
- 36 Illuminate
- 37 Stop switch
- 38 Timer controller (fuel filter switch)

■ C/D-type × B-type instrument panel




Figure 4

SYSTEM DIAGRAMS

- 1 Tachometer with hourmeter
- 2 -Buzzer
- 3 Buzzer stop
- 4 Illuminate
- 5 Starter switch
- 6 Stop switch
- 7 Relay
- 8 Relav
- 9 Engine stop solenoid
- 10 Air heater
- 11 Heater controller
- 12 Coolant temperature switch
- 13 Engine oil pressure switch
- 14 Starter relay
- 15 Coolant temperature switch
- 16 Procured by customer
 - $1 + 2 + 3 < 2.5 \text{ m} 20 \text{ mm}^2$
 - $1 + 2 + 3 < 5 \text{ m} 40 \text{ mm}^2$ (cross sectional area)
- 17 Battery
- 18 Battery switch
- 19-Starter
- 20 Alternator
- 21 Ground
- 22-6LPA-DTZP, STZP, STZP2
- 23 For 6LPA-DTZP, STZP, STZP2
- 24 Gear oil level switch
- 25 Coolant temperature sender
- 26 Engine oil pressure sender
- 27 Tachometer sensor
- 28 Boost sender
- 29 For 6LPA-DTZP, STZP, STZP2
- 30-6LPA-DTZP, STZP, STZP2
- 31 Coolant level switch
- 32 Drive trim sender
- 33 Timer controller (coolant level switch)
- 34 Fuel filter switch
- 35 Wire harness for 2-panel
- 36-Wire harness
- 37 Starter switch
- 38 Stop switch
- 39 Illuminate
- 40 Buzzer stop
- 41 Buzzer
- 42 Instrument panel
- 43 Tachometer with hourmeter
- 44 Coolant temperature meter
- 45 Engine oil pressure meter

- 46-Charge
- 47 Output status table
- 48 Gear oil
- 49 Fuel emp
- 50 Fuel filter
- 51 Boost
- 52 Diesel preheat
- 53-Coolant level
- 54 Exhaust
- 55 Coolant temperature
- 56 Engine oil pressure
- 57 Option: Harness adapter, Trim meter 119778-91500
- 58 Recommendation:

Marcruiser 79-817033A 4

- 59 Trim meter
- 60 Boost meter
- 61 Fuel filter
- 62 Diesel preheat
- 63 Exhaust
- 64 Coolant temperature
- 65 Engine oil pressure
- 66 Timer controller (fuel filter switch)

■ C/D-type × C-type instrument panel




Figure 5

SYSTEM DIAGRAMS

- 1 Engine oil pressure meter
- 2 Coolant temperature meter
- 3 Tachometer with hourmeter
- 4 Buzzer
- 5 Buzzer stop
- 6 Illuminate
- 7 Starter switch
- 8 Stop switch
- 9 Relay
- 10 Relay
- 11 Engine stop solenoid
- 12 Air heater (option)
- 13-Heater controller
- 14 Heater plug
- 15 Relay
- 16 Coolant temperature switch
- 17 Engine oil pressure switch
- 18 Starter relay
- 19 Coolant temperature switch
- 20 Procured by customer
 - $1 + 2 + 3 < 2.5 \text{ m} 20 \text{ mm}^2$
 - $1 + 2 + 3 < 5 \text{ m} 40 \text{ mm}^2$ (cross sectional area)
- 21 Battery
- 22 Battery switch
- 23-Starter
- 24 Alternator
- 25 Ground
- 26-6LPA-DTZP, STZP, STZP2
- 27 For 6LPA-DTZP, STZP, STZP2
- 28 Gear oil level switch
- 29 Coolant temperature sender
- 30 Engine oil pressure sender
- 31 Tachometer sensor
- 32 Boost sender
- 33 For 6LPA-DTZP, STZP, STZP2
- 34-6LPA-DTZP, STZP, STZP2
- 35 Coolant level switch
- 36 Drive trim sender
- 37 Timer controller (coolant level switch)
- 38 Fuel filter switch
- 39 Boost
- 40 Wire harness for 2-panel
- 41 Wire harness
- 42 Starter switch
- 43 Stop switch
- 44 Illuminate

- 45 Instrument panel (No. 2 station) option
- 46 Buzzer stop
- 47 Buzzer
- 48 Tachometer with hourmeter
- 49 Coolant temperature meter
- 50 Engine oil pressure meter
- 51 Charge
- 52 Engine oil pressure
- 53 Coolant temperature
- 54 Exhaust
- 55 Coolant level
- 56 Diesel preheat
- 57 Boost
- 58 Fuel filter
- 59 Fuel emp
- 60 Gear oil
- 61 Output status table
- 62-119778-91500 Option:

Harness adaptor,

Trim meter 119778-91500

- 63-79-817033A 4 Recommendation: Marcruiser 79-817033A 4
- 64 Trim meter
- 65 Boost meter
- 66 Gear oil
- 67-Fuel emp
- 68 Fuel filter
- 69 Boost
- 70 Diesel preheat
- 71 Coolant level
- 72 Exhaust
- 73 Coolant temperature
- 74 Engine oil pressure
- 75 Timer controller (fuel filter switch)

This Page Intentionally Left Blank

YANMAR CO., LTD.

■ Large Power Products Management Division

Quality Assurance Division

5-3-1, Tsukaguchi-honmachi, Amagasaki

Hyogo, 661-0001, Japan

Phone: +81-6-6428-3137 Fax: +81-6-6421-5549

https://www.yanmar.com/

■Yanmar Marine International B.V.

Brugplein 11, 1332 BS Almere-de Vaart, Netherlands Phone: +31-36-5493534 Fax: +31-36-5493219

http://www.yanmarmarine.eu/

Overseas Office

■Yanmar Europe B.V. (YEU)

Brugplein 11, 1332 BS Almere-de Vaart, Netherlands Phone: +31-36-5493200 Fax: +31-36-5493209 http://www.yanmar.eu/

■Yanmar Asia (Singapore) Corporation Pte. Ltd. (YASC)

4 Tuas Lane, Singapore 638613

Phone: +65-6861-3855 Fax: +65-6862-5189

https://www.yanmar.com/sg/

■ Yanmar America Corporation (YA)

101 International Parkway, Adairsville, GA 30103, U.S.A.

Phone: +1-770-877-9894 Fax: +1-770-877-9009

http://us.yanmar.com/

■ Yanmar Engine (Shanghai) Co., Ltd.

10F, E-Block Poly Plaza, No.18 Dongfang Road, Pudong Shanghai, China P.R.C. 200120

Phone: +86-21-6880-5090 Fax: +86-21-6880-8090

https://www.yanmar.com/cn/

As of May 1st, 2016

OPERATION MANUAL

6LPA-STP2, 6LPA-STZP2

1st edition: December 2010 2nd edition: April 2011 3rd edition: August 2011 4th edition: January 2012 5th edition: January 2017

Issued by: YANMAR CO., LTD. Large Power Products Management Division

Edited by: YANMAR TECHNICAL SERVICE CO., LTD.

YANMAR

YANMAR CO., LTD.

https://www.yanmar.com

0A6LP-EN0014